

TCA-1 Firmware Update Guide

Copyright(C) 2026 ZOOM CORPORATION. All Rights Reserved.


Proper display is not possible on grayscale devices.

Introduction

■Item to prepare



TCA-1



Compatible recorders
H2essential, H4essential, H6essential
H5studio, H6studio, F3, etc.



Windows or macOS computer
with Internet access



microSD card

Supported recording media

microSDHC: 4 GB – 32 GB

microSDXC: 64 GB – 2 TB

Always format microSD cards on the recorder
you are using after purchasing them new or
using them with a different device.

■Firmware update process


1. Download the firmware update file.
2. Extract the ZIP file.
3. Copy the extracted firmware update file to a microSD card.
4. Update the firmware.
5. Confirm that the firmware has been updated correctly.

Updating the Firmware

This guide explains firmware update to version 1.10 as an example.

1. Download the firmware update file



Download the ZIP file that contains the firmware update file from the TCA-1 download page.



On Windows


2. Extract the ZIP file

Select the folder that contains the downloaded ZIP file. Click ① “Compressed Folder Tools” and then click ② “Extract all”. This extracts the ZIP file.




3. Copy the firmware update file to a microSD card.

Copy the “TCA-1.bin” file to a microSD card.



Firmware update file

microSD card



Copy the firmware update file to a microSD card.

On macOS

2. Extract the ZIP file.


After downloading, open the ①“Downloads” folder which appears at the right end of the Dock by default.

Then, click ②. Downloaded files will be shown



3. Copy the firmware update file to a microSD card.

Copy the “TCA-1.bin” file to a microSD card.



The following procedures are the same on both Windows and macOS.

⇒ [**For the H2essential**](#)


⇒ [**For the H4essential and H6essential**](#)

⇒ [**For the H5studio and H6studio**](#)


⇒ [**For the F3**](#)

For the H2essential


1. Insert the microSD card into the recorder and turn the power on.
The Home Screen will appear.
2. Press the  (menu) button when the Home Screen is open.
The Menu Screen will appear.
3. Use  (operation button 2) /  (operation button 3) to select "Timecode (TCA-1)" and press **ENTER** (operation button 4) to confirm.




4. Use  (operation button 2) /  (operation button 3) to select "Firmware (TCA-1)" and press **ENTER** (operation button 4) to confirm.



5. Press **UPDATE** (operation button 4).



6. Use **▲** (operation button 2)/ **▼** (operation button 3) to select "Execute" and press **✓** (operation button 4) to confirm.




The update will start, and a completion screen will appear after about 5 seconds.

[NOTE]

During the firmware update, do not turn the power off or remove the microSD card.


If the update fails, turn the power off once and confirm that the microSD card is loaded correctly. Then, turn the power on and try updating again.

7. Confirm that the firmware version has been updated to v1.10.




For the H4essential and H6essential


1. Insert the microSD card into the recorder and turn the power on.
The Home Screen will appear.
2. On the Home Screen, use the  (selection) dial to select  "SYSTEM" and press the  (ENTER) button.
This opens the System Settings Screen.
3. Use the  (selection) dial to select "Timecode (TCA-1)" and press the  (ENTER) button.




4. Use the  (selection) dial to select "Firmware (TCA-1)" and press the  (ENTER) button.



5. Select "Firmware Update" and press the  (ENTER) button.



6. Use the  (selection) dial to select "Execute" and press the  (ENTER) button.




The update will start, and a completion screen will appear after about 5 seconds.

[NOTE]

During the firmware update, do not turn the power off or remove the microSD card.


If the update fails, turn the power off once and confirm that the microSD card is loaded correctly. Then, turn the power on and try updating again.

7. Confirm that the firmware version has been updated to v1.10.




For the H5studio and H6studio


1. Insert the microSD card into the recorder and turn the power on.
The Home Screen will appear.
2. On the Home Screen, use the  (selection) dial to select  "SYSTEM" and press the  (ENTER) button.
This opens the System Settings Screen.
3. Use the  (selection) dial to select "Timecode (TCA-1)" and press the  (ENTER) button.




4. Use the  (selection) dial to select "Firmware (TCA-1)" and press the  (ENTER) button.



5. Select "Firmware Update" and press the  (ENTER) button.



6. Use the  (selection) dial to select "Execute" and press the  (ENTER) button.




The update will start, and a completion screen will appear after about 5 seconds.

[NOTE]

During the firmware update, do not turn the power off or remove the microSD card.


If the update fails, turn the power off once and confirm that the microSD card is loaded correctly. Then, turn the power on and try updating again.

7. Confirm that the firmware version has been updated to v1.10.



For the F3


1. Insert the microSD card into the recorder and turn the power on.
The Home Screen will appear.
2. Press .
The Menu Screen will appear.
3. Use  /  to select "Timecode (TCA-1)" and press **ENTER** to confirm.



4. Use  /  to select "Firmware (TCA-1)" and press **ENTER** to confirm.



5. Press **UPDATE**.



6. Use  /  to select "Execute" and press  to confirm.




The update will start, and a completion screen will appear after about 5 seconds.

[NOTE]

During the firmware update, do not turn the power off or remove the microSD card.

If the update fails, turn the power off once and confirm that the microSD card is loaded correctly. Then, turn the power on and try updating again.

- 7.** Confirm that the firmware version has been updated to v1.10.



• ZOOM CORPORATION will bear no responsibility for any losses or third-party claims resulting from the use of this software. Moreover, distribution, sale, leasing, rental, alteration, and reverse engineering without permission of this software are prohibited. The specifications of this software and the contents of this document could be changed without notice in the future.

- Copying or reprinting this manual in whole or in part without permission is prohibited.
- Windows® is a trademark or registered trademark of Microsoft® Corporation.
- macOS® is a trademark or registered trademark of Apple Inc.
- microSDXC logos are trademarks of SD-3C LLC.
- Other product names, registered trademarks and company names in this document are the property of their respective companies.
- All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.
- The illustrations in these instructions might differ from actual screens.