

GUITAR EFFECTS & USB AUDIO I/F PEDAL



Operation Manual

Thank you for selecting the **ZOOM G1u** (hereafter simply called the "**G1u**"). Please take the time to read this manual carefully to get the most out of the unit and to ensure optimum performance and reliability. Keep this manual at hand for future reference.

Contents

SAFETY PRECAUTIONS / Usage Precautions 2	Using the G1u as an Audio Interface 20
Terms Used in This Manual 3	About ZFX Tools 20
Controls and Functions / Connections 4	Effect Types and Parameters 21
Selecting a Patch for Playing 6	Explanation of symbols 21
Using the Tuner 8	PATCH LEVEL 21
Using the Rhythm Function 10	COMP/EFX module 21
Using the Looping Function 12	DRIVE module 22
Editing a Patch 14	EQ module 23
Storing/Copying Patches 16	ZNR/AMP module 23
Restoring Factory Defaults 17	MODULATION module 24
Changing the Way Patches Are Called Up 18	DELAY module 25
Using a Foot Switch or Pedal 18	REVERB module 26
Using a foot switch 18	Rhythm Function Preset Patterns 27
Using an expression pedal 19	Checking the G1u Version 27
	Troubleshooting 27
	Specifications Rear cover



© ZOOM Corporation
Reproduction of this manual, in whole or in part,
by any means, is prohibited.

SAFETY PRECAUTIONS / Usage Precautions

SAFETY PRECAUTIONS

In this manual, symbols are used to highlight warnings and cautions for you to read so that accidents can be prevented. The meanings of these symbols are as follows:



This symbol indicates explanations about extremely dangerous matters. If users ignore this symbol and handle the device incorrectly, serious injury or death could result.



This symbol indicates explanations about dangerous matters. If users ignore this symbol and handle the device incorrectly, bodily injury and damage to the equipment could result.

Please observe the following safety tips and precautions to ensure hazard-free use of the G1u.

Power requirements



Since power consumption of this unit is fairly high, we recommend the use of an AC adapter whenever possible. When powering the unit from batteries, use only alkaline types.

[AC adapter operation]

- Be sure to use only an AC adapter ZOOM AD-0006 or AD-16. The use of an adapter other than the specified type may damage the unit and pose a safety hazard.
- Connect the AC adapter only to an AC outlet that supplies the rated voltage required by the adapter.
- When disconnecting the AC adapter from the AC outlet, always grasp the adapter itself and do not pull at the cable.
- During lightning or when not using the unit for an extended period, disconnect the AC adapter from the AC outlet.

[Battery operation]

- Use four conventional IEC R6 (size AA) batteries (alkaline).
- The G1u cannot be used for recharging.
- Pay close attention to the labelling of the battery to make sure you choose the correct type.
- When not using the unit for an extended period, remove the batteries from the unit.
- If battery leakage has occurred, wipe the battery compartment and the battery terminals carefully to remove all remnants of battery fluid.
- While using the unit, the battery compartment cover should be closed.

Environment



To prevent the risk of fire, electric shock or malfunction, avoid using your G1u in environments where it will be exposed to:

- Extreme temperatures

- Heat sources such as radiators or stoves
- High humidity or moisture
- Excessive dust or sand
- Excessive vibration or shock

Handling



• Never place objects filled with liquids, such as vases, on the G1u since this can cause electric shock.

• Do not place naked flame sources, such as lighted candles, on the G1u since this can cause fire.

• The G1u is a precision instrument. Do not exert undue pressure on the keys and other controls. Also take care not to drop the unit, and do not subject it to shock or excessive pressure.

• Take care that no foreign objects (coins or pins etc.) or liquids can enter the unit.

Connecting cables and input and output jacks



You should always turn off the power to the G1u and all other equipment before connecting or disconnecting any cables. Also make sure to disconnect all connection cables and the power cord before moving the G1u.

Alterations



Never open the case of the G1u or attempt to modify the product in any way since this can result in damage to the unit.

Volume



Do not use the G1u at a loud volume for a long time since this can cause hearing impairment.

Usage Precautions

Electrical interference

For safety considerations, the G1u has been designed to provide maximum protection against the emission of electromagnetic radiation from inside the device, and protection from external interference. However, equipment that is very susceptible to interference or that emits powerful electromagnetic waves should not be placed near the G1u, as the possibility of interference cannot be ruled out entirely.

With any type of digital control device, the G1u included, electromagnetic interference can cause malfunctioning and can corrupt or destroy data. Care should be taken to minimize the risk of damage.


Cleaning

Use a soft, dry cloth to clean the G1u. If necessary, slightly moisten the cloth. Do not use abrasive cleanser, wax, or solvents (such as paint thinner or cleaning alcohol), since these may dull the finish or damage the surface.

Please keep this manual in a convenient place for future reference.

Terms Used in This Manual

This section explains some important terms that are used throughout the G1u manual.



• Effect module

As shown in the illustration above, a patch in the G1u can be thought of as a combination of up to eight single effects. Each such effect is referred to as an effect module.

• Effect type

Some effect modules have several different effects which are referred to as effect types. For example, the MODULATION module is comprised of chorus, flanger, pitch shifter, and other effect types. Only one of these can be selected at a time.

• Effect parameter

All effect modules have various parameters that can be adjusted. These are called effect parameters or simply parameters. When thinking of an effect module as a compact effect, the parameters change the tone and effect intensity similar to the knobs on the device.

• Patch

In the G1u, effect module combinations are stored and called up in units referred to as patches. A patch is comprised of information about the on/off status and effect parameter settings used in each module.

• Bank



A group of ten patches is called a bank. The memory of the G1u is comprised of a total of 20 banks, labeled with letters A to J (user-editable banks) and numbers 0 to 9 (read-only preset banks), as shown in the illustration at top right.

• Mode

The internal status of the G1u is referred to as the operation mode. The function of keys and controls differs, depending on the respective mode. Modes of the G1u include play mode for selecting and playing patches, rhythm mode for playing a rhythm pattern, edit mode for modifying effects, and store mode for saving patches.

Operating the G1u on batteries

1. Turn the G1u over and open the cover of the battery compartment on the bottom.
2. Insert four fresh IEC R6 (size AA) batteries.
3. Close the cover of the battery compartment.



When the batteries are getting low, the indication "bt" appears on the display.

When operating the G1u on batteries, it is advisable to disconnect the guitar cable plug from the [INPUT] jack when not using the unit, to conserve battery power.

Top Panel

Module selector

Switches between play mode, rhythm mode, and edit mode. In edit mode, the knob selects the module/parameter for operation.

RHYTHM [▶/■] key

Serves to start and stop the rhythm pattern in play mode and rhythm mode.

Display

Shows bank and patch numbers, setting values, and other information for operating the G1u.

[VALUE] knob

This knob serves for changing parameter values and setting the level of the overall patch.

[STORE] key

Serves for storing edited patches in memory and for copying patches to another location.

[BANK UP-TAP] key

In play mode, the key switches to the next higher bank. In other modes, the key serves for manual adjustment of rhythm pattern tempo as well as parameters related to timing and cycle.

[▼]/[▲] foot switches

These switches are used for selecting patches, controlling the tuner, or the looping function.

Rear Panel

[USB] port

Serves for connecting the G1u to a computer. This allows using the G1u as an audio interface for the computer, and to edit and manage G1u settings using the computer.

[INPUT] jack

Serves for connecting the guitar. Inserting the guitar cable plug into this jack will turn the unit on.

When operating the G1u on batteries, it is advisable to disconnect the guitar cable plug from the [INPUT] jack when not using the unit, to conserve battery power.

[DC IN] jack

An AC adapter ZOOM AD-0006 or AD-16 can be plugged into this jack.

[CONTROL IN] jack

Serves for connection of the optional foot switch (FS01) or expression pedal (FP01/FP02).

FP01/FP02

[OUTPUT/PHONES] jack

This stereo phone jack serves for connection to the guitar amplifier. It is also possible to use a Y cable for sending the output to two amplifiers, or to plug a pair of stereo headphones into this jack.



Headphones

AC adapter

FS01

Guitar amplifier


Selecting a Patch for Playing (Play Mode)

This section explains basic functions of the play mode.

1 Turn power on


The volume control on the connected amplifier should be turned down.

Plug a shielded cable into the [INPUT] jack.



When using the unit with an AC adapter

Plug the cable from the adapter into the [DC IN] jack.



Turn the guitar amplifier on and adjust the volume to a suitable position.

HINT If the G1u is connected to a computer via a USB cable, and the AC adapter is not connected, power will be supplied via the USB port.

2 Set the G1u to play mode

Set the Module selector to "PLAY".



The bank and patch number are shown on the display.




HINT Immediately after turning the G1u on, the unit will be in play mode, regardless of the position of the Module selector.

3 Select a patch

Use the foot switches.


Press the [▲] foot switch to call up the next higher patch.



Press the [▼] foot switch to call up the next lower patch.



The unit cycles through patches in the order A0 – A9 ... J0 – J9 → 00 – 09 ... 90 – 99 → A0.



4 Directly switch a bank

Press the [BANK UP·TAP] key.

The unit cycles through banks in the order A ... J, 0 ... 9, A.

HINT You can also use an external foot switch (FS01) to switch banks (→ p. 18).



5 Adjust the master level

Operate the [VALUE] knob.

The master level setting appears on the display.

The master level setting applies to all patches. The setting range is 0 – 98, 1.0. It will be reset to 80 when power is turned off and then on again.



HINT When using headphones, this knob adjusts the listening volume.


Using the Tuner

To use the tuner function of the G1u, the built-in effects must be bypassed (temporarily turned off) or muted (original sound and effect sound turned off).

1 Switch to bypass or mute


• Setting the G1u to the bypass condition

In play mode or rhythm mode (→ p. 10), press both [▼]/[▲] foot switches together. When the indication "bP" appears on the display, release the switches within 1 second.



• Setting the G1u to the mute condition

In play mode or rhythm mode (→ p. 10), press both [▼]/[▲] foot switches together. Wait until the indication "bP" on the display changes to "Mt" and then release the switches within 1 second.



NOTE

- If you keep pressing the foot switches for more than 1 second after the indication "Mt" has appeared, the looping function (→ p. 12) will be activated.
- The bypass or mute condition cannot be activated when the unit is in edit mode (→ p. 14).

Patch change at bypass/mute

When you press both [▼]/[▲] foot switches together while playing your instrument, the sound may change momentarily just before the bypass/mute condition is activated. This is because the G1u switches to the next higher or lower patch when one of the foot switches is pressed slightly earlier. (When you cancel the bypass/mute condition, the original patch number will be

active again.)

This behavior is not a defect. It is due to the very high speed at which the G1u responds to patch switching. To prevent the sound change caused by the above condition, do not produce sound with your instrument until the bypass/mute condition is fully established.

2 Tune your instrument

Play the open string to tune, and adjust the pitch.

The left side of the display shows the note which is closest to the current pitch.

The right side of the display shows a symbol that indicates by how much the tuning is off.

A = $\overset{\frown}{A}$	C# = $\overset{\frown}{C\#}$	F = $\overset{\frown}{F}$
A# = $\overset{\frown}{A\#}$	D = $\overset{\frown}{D}$	F# = $\overset{\frown}{F\#}$
B = $\overset{\frown}{B}$	D# = $\overset{\frown}{D\#}$	G = $\overset{\frown}{G}$
C = $\overset{\frown}{C}$	E = $\overset{\frown}{E}$	G# = $\overset{\frown}{G\#}$

Pitch is high Pitch is correct Pitch is low

Indication turns faster the more the pitch is off


3 Adjusting the reference pitch of the tuner

To fine-adjust the reference pitch of the G1u tuner, turn the [VALUE] knob in the bypass/mute condition.

When you turn the knob, the current reference pitch is shown for a time on the display. The default setting is 40 (center A = 440 Hz).


While the reference pitch is shown, turn the [VALUE] knob to adjust the value in the range from 35 – 45 (center A = 435 to 445 Hz).

NOTE When power is turned off and on again, the reference pitch setting will be reset to 40 (center A = 440 Hz).



4 Return to play mode

Press one of the [▼]/[▲] foot switches.



Using the Rhythm Function (Rhythm Mode)

This section describes how to use the built-in rhythm function that plays realistic drum sounds in various patterns.

1 Select rhythm mode

Set the Module selector to the "RHYTHM" position.

The number of the currently selected rhythm pattern (01 – 40) appears on the display.

HINT In rhythm mode, the last selected patch will always be active. However, reverb effects are disabled while playing rhythm patterns. The rhythm function can also be used in play mode and looping mode.



2 Start the rhythm function

Press the RHYTHM [▶/■] key.


HINT Rhythm pattern playback will start also if you press the RHYTHM [▶/■] key in play mode. However, changing the rhythm pattern or adjusting the rhythm volume and tempo is not possible.



3 Select a rhythm pattern

To switch between the 40 built-in rhythm patterns, press one of the [▼]/[▲] foot switches. (For information on pattern contents, see page 27.)


HINT When you press both [▼]/[▲] foot switches in rhythm mode, the G1u switches to the bypass/mute condition. The tuning function (→ p. 8) can be used in this condition while playing the rhythm pattern.



4 Adjust the rhythm volume

Turn the [VALUE] knob.

The current setting (0 – 30) is shown briefly on the display.



5 Adjust the tempo



The rhythm pattern tempo can be adjusted in the range of 40 – 250 BPM (beats per minute).

• To continuously change the tempo



Hit the [BANK UP·TAP] key once and then turn the [VALUE] knob while the tempo value is being shown on the display.

• To manually specify the tempo

Hit the [BANK UP·TAP] key at least twice in the desired interval. The G1u automatically detects the interval in which the key is pressed the second and subsequent times, and sets the tempo accordingly (tap tempo function).



While the above steps are carried out, the new tempo value (40 – 250) is shown briefly on the display. For values in the range from 100 to 199, a dot is shown in the center, and for values of 200 and above, dots are shown in the center and in the bottom right corner.



HINT You can also use the foot switch (FS01) to specify the tempo (→ p. 18).

6 Stop the rhythm

Press the RHYTHM [▶/■] key.

The G1u returns to the previous condition.




Using the Looping Function (Looping Mode)

The G1u has a built-in looping function that can record and repeat up to five seconds of your play or record phrases as an overdub. This section describes how to use the looping mode.

1 Select looping mode

In play mode, press both [▼]/[▲] foot switches together and wait until the indication changes from "bP" to "Mt" and then to "LP". When "LP" is shown, release the switches.


NOTE In looping mode, delay effects are disabled.



2 Select the recording method

Turn the [VALUE] knob to select the recording method. The following settings are available.

- **1 – 8** Recording time is set using the current tempo setting, in quarter notes. For example, with a setting of "2", recording will stop automatically when two beats of the current tempo have elapsed.
- **Mn** Recording start and stop are controlled manually.



3 Adjust the tempo

If a setting from 1 to 8 was selected as recording method, use the [BANK UP·TAP] key and [VALUE] knob to set the tempo. The procedure is the same as for the rhythm function. The tap tempo function can also be used (→ p. 11).




4 Record/play a phrase

Press the [▲] foot switch and play the phrase to record. The indication changes to "rC" and recording starts.




- **When 1 – 8 was selected as recording method**
After the specified time has elapsed, recording terminates and loop playback starts.
- **When Mn was selected as recording method**
When the [▲] foot switch is pressed again, or when the maximum recording duration (5 seconds) is reached, recording terminates and loop playback starts. The display indication changes to "PL". To stop loop playback, press the [▼] foot switch. The display indication reverts to "LP".

NOTE When a 1 – 8 setting was selected, the maximum recording duration (5 seconds) may be exceeded, depending on the tempo. In such a case, recording will terminate when one half (or one quarter) of the selected time has elapsed.



5 Overdub a phrase


Perform recording as described in step 4. While the phrase is playing in loop playback, press the [▲] foot switch. The display indication changes to "rC" and overdub recording starts. When the end of the recorded phrase is reached, the unit returns to the beginning, and continues overdub recording. To stop overdub recording and return to loop playback, press the [▲] foot switch once more. The display indication changes to "PL". To stop loop playback, press the [▼] foot switch. The display indication reverts to "LP".



6 Clear the recorded content

Hold down the [▼] foot switch. The display indication changes to "CL", and the recorded content is cleared.

NOTE When you change the recording method or tempo setting, recorded content is also cleared.



7 Return to play mode

Press both [▼]/[▲] foot switches together.



Editing a Patch (Edit Mode)


The patches of the Glu can be freely edited by changing the effect type used by the various modules and by changing the parameter settings. Try editing the currently selected patch to create your own sound.

1 Select the effect module/parameter

Turn the Module selector to select the effect module and parameter to edit. The available settings are listed below.

- (1) PATCH LEVEL (Prm)
- (2) COMP/EFX module (Type&Prm)
- (3) DRIVE module (Type)
- (4) DRIVE module (Prm)
- (5) – (7) EQ module (Prm)
- (8) ZNR/AMP module (Type&Prm)
- (9) MODULATION module (Type&Prm1)
- (10) MODULATION module (Prm2)
- (11) DELAY module (Type&Prm1)
- (12) DELAY module (Prm2)
- (13) REVERB module (Type&Prm1)
- (14) REVERB module (Prm2)



The "Type" and "Prm" indication in brackets indicates the item category.



The EQ module has three parameters, and the MODULATION, DELAY, and REVERB modules have two parameters each. Switching the type gives access to the second and third parameter.

• Type&Prm or Type&Prm1 (Type & Parameter)

Item where the effect type (left side of display) and parameter setting value (right side of display) are adjusted simultaneously.



• Type

Item where the effect type only is selected.

• Prm or Prm2 (Parameter)

Item where the parameter setting value only is adjusted.

2 Change the setting

Turn the [VALUE] knob.

The setting of the selected item changes, and a dot (.) appears in the bottom right of the display. This indicates that a setting has been changed from the currently stored value.



Dot indicates that setting has been changed

HINT

When you have selected a parameter that can be set with the tap function (→ p. 21), you can repeatedly hit the [BANK UP-TAP] key at the desired interval to specify the timing.

3 To switch an effect module on and off

Press one of the [▼]/[▲] foot switches.

The indication "oF" appears on the display and the module is turned off. Pressing one of the switches once more returns the setting to the previous condition.



4 Terminate the edit mode

Set the Module selector to the "PLAY" position to return to the play mode.

NOTE

When you return to play mode and have made any changes to the patch, the dot (.) will be shown in the bottom right of the display. If you select another patch in this condition, the changes you have made in edit mode will be lost unless you store the patch first. To retain the changes, store the patch as described on page 16.



Storing/Copying Patches (Store Mode)

An edited patch can be stored in the user-editable banks (A – J). It is also possible to store an existing patch in another location to create a copy.

1 In play mode or edit mode, press the [STORE] key

The bank and patch number flash on the display.

NOTE Patches of the preset banks (0 – 9) are read-only. No patches can be stored or copied into these locations. If you press the [STORE] key while a patch from the preset area is selected, the patch "A0" (bank A, patch number 0) will be selected automatically as default store/copy target.



2 Select the store/copy target bank and patch number

- Use the [▼]/[▲] foot switches to select the bank/patch number.

- To switch only the bank, use the [BANK UP-TAP] key.

NOTE

- Only a user-editable bank (A – J) can be selected as store/copy target bank.
- During the store/copy process, the foot switch (FS01) cannot be used to change banks.



3 Press the [STORE] key once more

When the store/copy process is completed, the G1u returns to the previous mode, with the target patch selected.

HINT To cancel the store process, operate the [VALUE] knob before pressing the [STORE] key again.



Restoring Factory Defaults

Even after overwriting user patches with other patches, their original content can be restored in a single operation ("All Initialize" function).

To do this, turn power to the G1u on while holding down the [STORE] key.

The indication "AL" appears on the display.

To carry out the All Initialize function, press the [STORE] key once more. All patch settings are returned to the factory default condition, and the unit switches to play mode.

To cancel All Initialize, press the RHYTHM [▶/■] key instead of the [STORE] key.



NOTE When you carry out All Initialize, any newly created patches that were stored in the user-editable bank will be deleted (overwritten). Perform this operation with care to prevent losing any patches that you want to keep.

Changing the Way Patches Are Called Up

This section describes how to change the patch selection method of the G1u to "pre-select". In this mode, you first select the patch to use next, and then perform an additional step to activate the patch.

1. Turn power to the G1u on while holding down the [▲] foot switch.

The indication "PrE-SElEct" scrolls on the display.


2. In play mode, select the patch to use next.




The selected new bank and patch number flash on the display. The sound does not change yet.



3. When you have specified the patch to use, press both [▼]/[▲] foot switches together.



The patch change is accepted, causing the sound to change, and the display changes from flashing to permanently lit.



4. To return the G1u to the normal patch selection method, simply turn power off and then on again.

The patch selection method is automatically reset to conventional operation.

• Edit mode/Store mode

The foot switch has no effect.



Using an expression pedal

When the optional expression pedal (FP01/FP02) is connected to the [CONTROL IN] jack of the G1u, you can change effect parameters in real time or use the pedal as a volume controller. The function of the expression pedal can be saved individually for each patch.

1. Plug the FP01/FP02 into the [CONTROL IN] jack.

2. In play mode, select a patch for which you want to use the expression pedal.

3. Set the Module selector to a position other than "PLAY" or "RHYTHM".



The G1u goes into edit mode.

4. Hold down the RHYTHM [▶/■] key and turn the [VALUE] knob to select one of the following modules for control by the expression pedal.

Display	Control target
oF	Off
vP	Volume
uP	COMP/EFX module
dP	DRIVE module
mP	MODULATION module
lP	DELAY module
rP	REVERB module

- HINT**
- In the section "Effect Types and Parameters" (→p. 21), effect types/parameters that can be controlled with the expression pedal are indicated by a pedal symbol.
 - If a module is selected for which no pedal symbol is shown, the expression pedal will have no effect for that patch.

5. Save the patch.

The expression pedal setting is stored with the patch.

6. In play mode, select the patch and operate the expression pedal.

The respective parameter changes. In bypass mode, the expression pedal always functions as a volume pedal, regardless of the setting.

- HINT** The expression pedal operates also in edit mode.

Using a Foot Switch or Pedal

This section explains how to use an optional foot switch or expression pedal.

Using a foot switch

When an optional foot switch (FS01) is connected to the [CONTROL IN] jack of the G1u, you can switch banks and specify the tempo for rhythm patterns with the foot switch. Depending on the currently selected mode, the foot switch operates as follows.

• Play mode

Pressing the foot switch selects the next higher bank.

• Rhythm mode/Looping mode

When you press the foot switch two times or more, the G1u detects the interval and automatically adjusts the tempo accordingly (tap tempo function).

Using the G1u as an Audio Interface

When the G1u is connected to a computer via the USB port, it can function as an audio interface for the computer. The operating environment conditions for this type of use are as follows.

Compatible operating systems

- Windows XP SP2 or later
Windows Vista or later
- MacOS X (version 10.4.6 or later/10.5 or later)

Quantization

16-bit


Sampling frequencies

32 kHz / 44.1 kHz / 48 kHz

With the operating systems listed above, the G1u will function as an audio interface simply by connecting the USB cable. There is no need to install any special driver software. However, the supplied dedicated ASIO driver allows low-latency audio recording and playback.

HINT If the G1u is connected to a computer via a USB cable, and the AC adapter is not connected, power will be supplied via the USB port.

In this condition, the sound of a guitar connected to the [INPUT] jack of the G1u can be processed with the effects of the G1u and then be recorded on the audio tracks of a DAW (Digital Audio Workstation) software application running on the computer.



At the same time, the [OUTPUT] jack of the G1u carries the playback sound from the audio tracks of the DAW application, mixed with the guitar sound processed by the effects of the G1u. For details on recording and playback steps, refer to the documentation of the DAW application.

- NOTE**
- Also when using the G1u as an audio interface, the signal after effect processing is always available directly at the [OUTPUT] jack (allowing use of the unit as an effect).
 - If the DAW application has an echo back function (input signal during recording is supplied directly to an output), this must be disabled when using the G1u. If recording is carried out with this function enabled, the output signal will sound as if processed by a flanger effect.
 - Use a high-quality USB cable and keep the connection as short as possible. If power is supplied to the G1u via a USB cable that is more than 3 meters in length, the low voltage warning indication may appear.

About ZFX Tools

The G1u is supplied with a software application called ZFX Tools which comprises editor/librarian functions and recording functions.

When the G1u is connected to a computer via USB, ZFX Tools can be used to import patch data from the G1u to the computer for editing and storage, and the signal from the G1u can be recorded on the computer.

Effect Types and Parameters

Explanation of symbols

Module selector



Shows the position of the knob at which this module/parameter is called up.

Expression pedal



Indicates a parameter that can be controlled with the expression pedal.

Tap



Indicates a parameter that can be set by repeatedly tapping the [BANK UP·TAP] key. When the module/effect type is selected in edit mode, the parameter (modulation rate or delay time, etc.) will be set according to the interval in which the key is pressed.




* Manufacturer names and product names mentioned in this listing are trademarks or registered trademarks of their respective owners. The names are used only to illustrate sonic characteristics after which the effects are modeled and do not indicate any affiliation with ZOOM CORPORATION.
For some effect modules, you can select an effect type from several possible choices.

PATCH LEVEL

	PATCH LEVEL (Prm)
	Sets the overall volume level of the patch.
	The setting range is 2 – 98, and 1.0. A setting of 80 corresponds to unity gain (input level and output level are equal).


COMP/EFX (Compressor/Special Effects) module

	COMP/EFX (Type&Prm)
	Selects the COMP/EFX module effect type and parameter.
	Compressor
	This is an MXR Dynacomp type compressor which limits high-level signals and boosts low-level signals to compress the overall dynamics of the signal. Higher settings result in higher sensitivity.
	Auto Wah
	This effect varies wah in accordance with picking intensity. Higher settings result in higher sensitivity.
	Booster
	Raises signal gain and creates a dynamic sound. Higher settings result in higher gain.
	Tremolo
	This effect periodically varies the volume. Higher settings result in faster modulation rate.
	RingMod (Ring Modulator)
	This effect produces a metallic ringing sound. Higher settings result in higher modulation frequency.
	Slow Attack
	This effect reduces the attack rate of each individual note. Higher settings result in slower attack times.

	Pedal Vox 
	This effect simulates a vintage Vox wah pedal at half-open. Higher settings shift the emphasized frequency upwards.
	Pedal Cry 
	This effect simulates a vintage Jen Crybaby pedal at half-open. Higher settings shift the emphasized frequency upwards.
	Octave 
	This effect adds a one-octave lower component to the original sound. Higher settings result in higher effect mix ratio.



■ **DRIVE module (distortion effects)**

	DRIVE (Type)	
	Selects the effect type for the DRIVE module.	
	FD COMBO	
	Sound of a Fender Twin Reverb ('65 model) favored by guitarists of many music styles.	Sound modeled on the Class A drive combo amp Vox AC30.
	US BLUES	
	Crunch sound of a Fender Tweed Bassman.	Crunch sound of the Mesa Boogie MkIII combo amp.
	HW STACK	
	Sound of the legendary all-tube Hiwatt Custom 100 from Britain.	Crunch sound of the Marshall 1959 that has become legendary.
	MS DRIVE	
	High gain sound of the Marshall stack amp JCM2000.	High gain sound of a Peavey 5150 developed in cooperation with a world-famous hard rock guitarist.
	DZ DRIVE	
	High gain sound based on the channel 3 of the hand-made German guitar amp Diezel Herbert with three separately controllable channels.	High gain sound of the Mesa Boogie Dual Rectifier red channel (vintage mode).
	OVER DRIVE	
	Sound of the Boss OD-1 that first created the "overdrive" concept.	Simulation of the often copied Ibanez TS808 used by many guitarists as a booster.
	GOVERNOR	
	Sound of the Guv'nor distortion effect from Marshall.	Simulation of MXR distortion+ that made distortion popular worldwide.
	Dist1	
	Sound of the Boss distortion DS-1, a long-time favorite.	Simulation of the ProCo Rat famous for its edgy distortion sound.
	FUZZ SMILE	
	Sound of the Fuzz Face that made rock history with its zany look and smashing sound.	Simulation of the Electro-Harmonix Big Muff preferred by famous artists for its fat, sweet fuzz sound.
	METAL WORLD	
	Sound of the Boss Metal Zone with long sustain and dynamic lower midrange.	Simulation of the compact Matchless HotBox preamp with built-in tubes.


	Z CLEAN	
	Zoom original flat clean sound.	High-gain sound with further boost in the overdrive.
	Z MP1	
	Original sound that combines characteristics of the ADA MPI and Marshall JCM800.	High-gain sound with pronounced low and mid range.
	Z DREAM	
	High-gain sound for lead guitar based on the Lead channel of the Mesa Boogie Road King Series II.	Original high-gain sound with good balance from the low to high range.
	Z NEOS	
	Crunch sound modeled on a modified Vox AC30.	Smooth, bright distortion sound.
	EXTREME DS	
	High gain sound with the most powerful gain of any distortion effect in the world.	ACO.SIM (Acoustic Simulator)
		This effect makes an electric guitar sound like an acoustic guitar.
	GAIN (Prm)	
	Sets the DRIVE module parameters. The parameter action differs, depending on whether a distortion effect type (Fd – Ed) or Aco.Sim (Ac) is selected.	
	When distortion effect type (Fd – Ed) is selected	
	GAIN 	
	Adjusts the gain (distortion intensity).	
	When Ac is selected	
	TOP 	
	Adjusts the characteristic string tone of acoustic guitar.	

* Manufacturer names and product names mentioned in this listing are trademarks or registered trademarks of their respective owners. The names are used only to illustrate sonic characteristics after which the effects are modeled and do not indicate any affiliation with ZOOM CORPORATION.

■ **EQ module (equalizer)**

	EQ LO (Prm)		EQ MID (Prm)		EQ HI (Prm)
	Adjusts the LO band of the EQ module.		Adjusts the MID band of the EQ module.		Adjusts the HI band of the EQ module.
	Lo		Mid		Hi
	Adjusts the low range (160 Hz) boost/cut.		Adjusts the midrange (800 Hz) boost/cut.		Adjusts the high range (3.2 kHz) boost/cut.

■ **ZNR/AMP (ZNR/Amp Simulator) module**

	ZNR/AMP (Type&Prm)
	This module combines ZOOM's proprietary ZNR (removes noise during play pauses without affecting sound quality) with an amp simulator (recreates the sound of various speaker cabinets). Type and parameters are adjusted at the same time.
	ZNR (ZOOM Noise Reduction)
	This is the noise reduction function only. Higher settings result in a stronger effect. Set the value as high as possible without causing the sound to be cut off unnaturally.

	Combo & ZNR Combination of ZNR with amp simulator that recreates the sound of a combo amp with closed-back cabinet. The right-digit value controls ZNR sensitivity.
	Bright Combo & ZNR Combination of ZNR with amp simulator that recreates the sound of a bright combo amp with open-back cabinet. The right-digit value controls ZNR sensitivity.
	Stack & ZNR Combination of ZNR with amp simulator that recreates the sound of a stack amp cabinet. The right-digit value controls ZNR sensitivity.

■ MODULATION module

	MODULATION (Type&Prm1) Selects the MODULATION module effect type and controls parameter 1 at the same time.		RATE (Prm2) Controls the value of parameter 2 of the MODULATION module. The parameter action differs, depending on the effect type.
	Chorus This effect mixes a variable pitch-shifted component to the original signal. Higher right-digit settings result in higher effect sound mixing ratio.		Rate Adjusts the modulation rate.
	Ensemble This is a chorus ensemble with three-dimensional movement. Higher right-digit settings result in higher effect sound mixing ratio.		
	Flanger This effect produces a resonating and strongly undulating sound. Higher right-digit settings emphasize the characteristics of the effect.		Rate
	Step Special effect that changes the sound in a staircase pattern. Higher right-digit settings emphasize the characteristics of the effect.		
	Pitch Shift This effect shifts the pitch of the original sound up or down. Higher right-digit settings increase the mixing ratio of the effect sound.		Shift
	Mono Pitch This is a monophonic pitch shifter (for single-note playing) with reduced flutter. Higher right-digit settings increase the mixing ratio of the effect sound.		Sets the pitch shift amount in semitones. "dt" results in a detune effect.
	HPS (Harmonized Pitch Shifter) This is an intelligent pitch shifter that automatically generates major scale harmonies according to a preset key. Higher right-digit settings increase the mixing ratio of the effect sound.		Key Specifies the tonic for the scale used for pitch shifting. The "o" symbol stands for #.

	Vibrato This is an effect with automatic vibrato. Higher right-digit settings emphasize the vibrato intensity.		Rate
	Pitch Bend This effect allows using the expression pedal to change the pitch in real time. Right-digit settings select the pitch change type caused by the expression pedal (see Table 1).		Pedal Position Sets the initial value for the pitch shift amount (the value that is active when the pedal is at rest). The original sound/effect sound level balance also changes according to the parameter 1 setting.






[Table 1]

Type&Prm1	Prm2=0	Prm2=1.0	Type&Prm1	Prm2=0	Prm2=1.0
	Pedal fully raised (minimum)	Pedal fully depressed (maximum)		Pedal fully raised (minimum)	Pedal fully depressed (maximum)
b1	0 cent	+1 octave	b6	-1 octave + original sound	+1 octave + original sound
b2	0 cent	+2 octaves	b7	-700 cent + original sound	+500 cent + original sound
b3	0 cent	-100 cent	b8	Doubling	Detune + original sound
b4	0 cent	-2 octaves	b9	-∞(0Hz) + original sound	+1 octave + original sound
b5	0 cent	-∞			







	Delay This is a delay with a maximum setting of 2000 msec. Higher right-digit settings increase the mixing ratio of the effect sound and the feedback amount.		Time (Delay Time)
	CombFilter This effect uses the comb filter characteristics generated by using fixed modulation on the flanger as an equalizer. Higher settings increase the mixing ratio of the effect sound.		Frequency Sets the frequency to be emphasized by the filter. Higher settings shift the emphasized frequency upwards.
	Air This effect reproduces the ambience of a room, to create spatial depth. Higher settings increase the mixing ratio of the effect sound.		Size Sets the size of the simulated space. Higher settings values make the space bigger.
	Phaser This effect produces sound with a pulsating character. The setting values change the type of sound.		Rate

■ DELAY module

	DELAY (Type&Prm1) Selects the DELAY module effect type and controls parameter 1 at the same time.
	Delay This is a delay with a maximum setting of 5000 msec. The right-digit setting values control the mixing ratio of the effect sound and the feedback amount.
	Tape Echo This effect simulates a tape echo with a long delay time of up to 5000 msec. The right-digit setting values control the mixing ratio of the effect sound and the feedback amount.

	Analog Delay 
	This effect simulates an analog delay with a long delay time of up to 5000 msec. The right-digit setting values control the mixing ratio of the effect sound and the feedback amount.
	Ping Pong Delay 
	This is a ping-pong type delay where the delay sound alternates between left and right. The right-digit setting values control the mixing ratio of the effect sound and the feedback amount.
	Reverse 
	This is a special delay where the effect sounds as if playing in reverse. Maximum delay time is 2500 msec. Higher settings result in stronger effect sound.
	TIME (Prm2)
	Controls parameter 2 of the DELAY module. The setting range is different for the Reverse effect type and other effect types.
When Delay – Ping Pong Delay is selected	
	Time (Delay Time) 
	Sets the delay time. In the 10 – 1000 millisecond range, the adjustment is performed in 10-msec steps (1 – 99, 1.0). Above 1 second, the adjustment is performed in 100-msec steps (1.1 – 5.0).
When Reverse is selected	
	Time (Delay Time) 
	Sets the delay time. In the 10 – 1000 millisecond range, the adjustment is performed in 10-msec steps (10 – 99, 1.0). Above 1 second, the adjustment is performed in 100-msec steps (1.1 – 2.5).

■ REVERB module

	REVERB (Type&Prm1)
	Selects the REVERB module effect type and controls parameter 1 at the same time.
	Hall 
	This reverb effect simulates the acoustics of a concert hall. Higher right-digit settings increase the mixing ratio of the effect sound.
	Room 
	This reverb effect simulates the acoustics of a room. Higher right-digit settings increase the mixing ratio of the effect sound.
	Spring 
	This effect simulates a spring-type reverb. Higher right-digit settings increase the mixing ratio of the effect sound.
	Arena 
	This reverb effect simulates the acoustics of a large venue such as a sports arena. Higher right-digit settings increase the mixing ratio of the effect sound.
	Tiled Room 
	This reverb effect simulates the acoustics of a tiled room. Higher right-digit settings increase the mixing ratio of the effect sound.
	DECAY (Prm2)
	Controls parameter 2 of the REVERB module. This parameter is common to all effect types.
	Decay
	Adjusts the decay duration.

Rhythm Function Preset Patterns

#	Name	TimSig	#	Name	TimSig	#	Name	TimSig	#	Name	TimSig
1	8beat 1	4/4	11	METAL 2	4/4	21	POP 3	4/4	31	BALLAD 1	4/4
2	8beat 2	4/4	12	THRASH	4/4	22	DANCE 1	4/4	32	BALLAD 2	3/4
3	8beat 3	4/4	13	PUNK	4/4	23	DANCE 2	4/4	33	BLUES 1	4/4
4	8shuffle	4/4	14	DnB	4/4	24	DANCE 3	4/4	34	BLUES 2	3/4
5	16beat 1	4/4	15	FUNK 1	4/4	25	DANCE 4	4/4	35	JAZZ 1	4/4
6	16beat 2	4/4	16	FUNK 2	4/4	26	3per4	3/4	36	JAZZ 2	3/4
7	16shuffle	4/4	17	HIPHOP	4/4	27	6per8	3/4	37	METRO 3	3/4
8	ROCK	4/4	18	R'nR	4/4	28	5per4 1	5/4	38	METRO 4	4/4
9	HARD	4/4	19	POP 1	4/4	29	5per4 2	5/4	39	METRO 5	5/4
10	METAL 1	4/4	20	POP 2	4/4	30	LATIN	4/4	40	METRO	

Checking the G1u Version

Checking the G1u Software Version, perform the following steps.

1. Turn power to the G1u on while holding down the [BANK UP-TAP] key and the [▲] foot switch.

The higher two digits of the current version are shown on the display.

2. Press the [▲] foot switch.

The lower two digits of the current version are shown on the display.

3. Pressing either of the [▼]/[▲] foot switches causes the version display to go off, and the G1u restarts.

Detailed information about the latest software version can be found on the ZOOM web site: <http://www.zoom.co.jp/>

Troubleshooting

- **No power**
Refer to "Turn power on" on page 6.
- **Reverb effect does not operate**
While a rhythm pattern is playing, the reverb effect is not available. Stop the rhythm pattern first (→ p. 10).
- **Delay effect does not operate**
While the looping function is being used, the delay effect is not available. Stop the looping function first (→ p. 12).
- **Patch switching does not change the**

sound

Is the patch selection method of the G1u set to "pre-select" (→ p. 18)? Turn power off and then on again to return to normal operation.

- **High level of noise**
Is ZOOM AC adapter being used? Be sure to use only an AC adapter ZOOM AD-0006 or AD-16.
- **Battery life is short**
Are manganese batteries being used? Continuous operation time is about 10 hours with alkaline batteries.

Specifications

Effect types	67	Control input	For FP01/FP02 or FS01
Effect modules	max. 8 simultaneous modules	USB interface	16-bit PC interface (one line each for stereo record/play)
Patch memory	User banks: 10 patches x 10 banks = 100 Preset banks: 10 patches x 10 banks = 100 Total 200 patches	Sampling frequencies	32 kHz, 44.1 kHz, 48 kHz
Sampling frequency	96 kHz	Power requirements	
A/D converter	24 bit 64 times oversampling	AC adapter	ZOOM AD-0006, AD-16
D/A converter	24 bit 128 times oversampling	Batteries	Four IEC R6 (size AA) batteries, approx. 10 hours continuous operation (alkaline batteries)
Signal processing	32 bit	USB bus power	
Frequency response	20 Hz – 40 kHz +1.0 dB –4.0 dB (10-kilohm load)	Dimensions	155 mm (D) x 136 mm (W) x 52 mm (H)
Display	2-digit 7-segment LED	Weight	350 g (without batteries)
Input	Standard mono phone jack	Options	Expression pedal FP01/FP02 or Foot switch FS01
Rated input level	-20 dBm		
Input impedance	470 kilohms		
Output	Standard stereo phone jack (doubles as line/headphone jack)		
Maximum output level	Line +3 dBm (output load impedance of 10 kilohms or more) Phones 20 mW + 20 mW (into 32-ohm load)		

The FCC regulation warning (for U.S.A.)


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

For EU Countries



Declaration of Conformity:
This product complies with the requirements of EMC Directive 2004/108/EG and Low Voltage Directive 2006/95/EC



Disposal of Old Electrical & Electronic Equipment (Applicable in European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

ZOOM

ZOOM CORPORATION

4-4-3, Kandasurugadai, Chiyoda-ku, Tokyo 101-0062, Japan
Web Site: <http://www.zoom.co.jp>

G1u - 5000-5

**GUITAR EFFECTS &
USB AUDIO I/F PEDAL**

G1u.



PATCH LIST

- The preset area of banks 0 – 9 contains the same patches as A – J.
- We recommend you to adjust the Noise Reduction parameter according to your guitars, amps and recording or performance situation.

Manufacturer names and product names mentioned in this patch list are trademarks or registered trademarks of their respective owners and do not indicate any affiliation with ZOOM CORPORATION. All product and artist names are intended only to illustrate sonic characteristics that were used as reference in the development of this product.



	PATCH NAME	COMMENT
DEMO A	0	ArenaLd Sharp-edged high-gain lead sound using MS DRIVE with Delay and Arena reverb added.
	1	OGRhythm 70's British rock sound using MS CRUNCH and Booster.
	2	ChoCln Great clean sound for Arpeggios. Using the Compressor, Chorus and Reverb gives a wide, fat tone with a nice attack.
	3	BigDuck Auto wah sound using slightly distorted fullup FD COMBO plus Spring reverb. The tone responds to volume knob changes.
	4	JetFly Combination sound of MS CRUNCH and Flanger. Great for chords or muted lower strings.
	5	MdrnPnk Powerful modern punk sound. Great for rhythm tracks.
	6	TrickDly Clean sound using two delays set for different delay times.
	7	PhaseCLN Clean sound using FD COMBO and Phaser. Great for funk rhythm.
	8	LapStID Lap Steel modeled sound using FD COMBO and H.P.S. Great for slide parts. Set to key of D.
9	WetWood Acoustic guitar sound using chorus and reverb. Use with a single coil neck pickup for best results.	
DEMO B	0	MtlMtl ZOOM's original Z BOTTOM metal sound with chorus. A wide, high-gain sound. Great for 80's metal.
	1	VntgPnk Punk crunch sound. This slightly distorted sound works great with Les Pauls and Telecasters.
	2	JazzWet Fat clear jazz sound created by boosting the low end with EQ. Use a neck position humbucking pickup for the most authentic results.
	3	ChnkBluz US BLUES crunch sound. This clear and bright sound is great for both blues rhythm playing and solos.
	4	RaGaRthm Clean reggae sound with a nice high frequency attack. Made with Spring reverb and chorus.
	5	CompCln Powerful compressed clean sound.
	6	ClscFuzz Authentic Fuzz sound using GREAT MUFF and Compressor. A nice, even fuzz tone for all guitars.
	7	Church Compressed clean sound with chorus and hall reverb. Great "cathedral sound" with open voiced chords.
	8	Niaga Psychedelic 60's sound using Slow Attack and Reverse.
9	DryWood Dry acoustic guitar sound with a touch of ambience. Great for finger picking and chord strumming. Use with a single coil neck pickup for best results.	

	PATCH NAME	COMMENT
ARTIST C	0	LiverPL Day Tripper intro style sound. VOX sound works with both single coil or humbucking pickups.
	1	JimiFuzz The "Jimi" style fuzz sound. The pitch shifter adds an octave up to emulate an Octavia.
	2	ZepStd Early Page "Zep style" recording sound. Bright and crunchy.
	3	EC LEAD "Layla" style sound. Fender crunch, great with single coil pickups.
	4	lomizm "Paranoid" style sound.
	5	RitchStd "Machine Head" style sound.
	6	BrianDrv Uses the Z NEOS drive to make a May, "Queen" style sound.
	7	JB Boots "Led Boots" intro style sound. Nice, warm echoes.
	8	335 Solo "Room 335" style sound. Sustained lead sound with a little bit of delay.
9	EVH1959 Early "EVH" style sound using Marshall 1959. Sounds best with humbucking pickups.	
ARTIST D	0	FineRose "Crazy Train" style sound. Rhoads / Marshall 80's metal.
	1	BS Riff Rockabilly sound for "Rock This Town" style sound. This echoed tone responds to picking dynamics.
	2	Police "Every Breath You Take" style sound. Great sound made by mixing chorus and delay.
	3	SRV TS808 "SRV" style sound. Nice mids and sounds great with a Strat.
	4	SV DS1 "Attitude Song" style sound. Utilizes DS1 metal sound.
	5	Lynchpin "Kiss of Death" style sound. Metallic saturated sound for 80's style metal.
	6	SilkyJoe "Surfing with the Alien" style sound. Edgy distortion sound with a touch of modulation.
	7	WizenDrv "Into The Arena" style sound. Similar to MSG tone with the wah in the middle position.
	8	DeepSand "Enter Sandman" style sound. Deep metal sound, great for heavy riffs.
9	Carlos Smooth "Carlos S" solo recording sound using the BG CRUNCH.	

	PATCH NAME	COMMENT
M MODELING	0	FdComp Fender Twin Reverb and compressor. Great for clean funk rhythm playing.
	1	FullVx Overdriven Vox AC30 with room reverb. The reverb adds a unique closed back like sound.
	2	TexasMan Texas blues sound of a Fender Bassman on 10. The sound responds to the guitar's volume knob. Great for blues.
	3	BgLead MESA/BOOGIE MKIII drive sound. Great for sustained leads.
	4	HwClean Fat clean sound of HIWATT CUSTOM 100. Great rock clean sound.
	5	McCrunch Marshall 1959 classic crunch sound.
	6	MdRhythm Marshall JCM2000 rhythm sound. Heavy, but still classic Marshall sound.
	7	PvRhythm Peavey 5150 rhythm sound. Great for metal rhythm.
	8	DzRhythm Diezel Herbert heavy rhythm sound. Great for tuned down guitars.
9	BdRhythm MESA/BOOGIE Rectifier rhythm sound. Great for the progressive metal.	
T MODELING	0	FatOd Natural overdriven sound using OD-1 and EQ. Great for both lead and rhythm.
	1	TsDrive Tube Screamer overdriven sound. Great for blues to rock.
	2	GvDrive Guv'nor pedal hard rock sound.
	3	dist+ MXR distortion+ drive sound.
	4	DS1 DS-1 pedal sound modded with some extra low end.
	5	RAT RAT pedal long sustained lead sound.
	6	FatFace FUZZ FACE with added some low end.
	7	MuffDrv BIG MUFF high gain sound.
	8	M World Classic Metal Zone shred sound.
9	HOT DRV Mild drive sound made by a tube saturation feel. Even though it is hard driving but still has a strong core in the sound.	
G ORIGINAL	0	Z CLEAN Crystal clean sound based on Z CLEAN with chorus and delay. Good for arpeggio playing.
	1	Z WILD ZOOM's original hard overdrive sound. Overdrive boost with compression.
	2	Z MP1 A combination of ADA MP1 and Marshall JCM800.
	3	Z BOTTOM ZOOM's original high gain sound. Rich depth in the mids and lows. Great for 80's metal.
	4	Z DREAM ZOOM's original high gain sound. Great for 7 strings or drop tuned guitar. Great progressive metal sound.
	5	Z SCREAM Well balanced tuning of ZOOM's original high gain sound. Sharp and cutting.
	6	Z NEOS Modified VOX AC30 crunch sound. Responds well to the guitar's volume knob.
	7	LEAD ZOOM's classic lead sound with strong mid-boost and long sustain.
	8	EXT DS Super saturated distortion sound. Full and smooth.
9	ACOSIM Acoustic guitar simulator. Sounds best with single coil pickups in the neck position.	

	PATCH NAME	COMMENT
H SIMPLE	0	Comprs Single knob compressor. Turn up the sensitivity for that pumping effect.
	1	Auto Wah Auto Wah. Set sensitivity to work with rhythm or lead lines.
	2	Booster Bright booster with punch and edge.
	3	Tremolo Rich versatile tremolo for all styles.
	4	Ring Mod Ring Modulator highlighting various harmonics.
	5	Slow Slow Attack creating the effect of using a volume pedal. Works well with full chords or lead.
	6	PDLWah 1 Vox Wah. Use the optional FP02 expression pedal to control.
	7	PDLWah 2 Cry Wah. Use the optional FP02 expression pedal to control.
	8	Octave Octave divider. Produces original note and one octave lower simultaneously.
9	Chorus Chorus. Warm, rich and appropriate for all styles.	
I SIMPLE	0	Ensemble Chorus ensemble. Natural and transparent great for clean arpeggios.
	1	Flanger Short feedback delay, sweeping flanger pedal.
	2	Step Adjustable step phaser. Effective with or without distortion.
	3	PitchSFT Pitch shifter up or down to create 12 string guitar effect.
	4	MN Pitch Mono pitch shifter for single note playing.
	5	H.P.S Harmonized pitch shifter set to the key of C major.
	6	Vibrato Automatic Vibrato sound.
	7	PitchBND Pitch bend. Use the optional FP02 expression pedal to control the amount of bend.
	8	Air Reverb creating an light spatial open effect.
9	Phaser Versatile phaser with four types to choose from.	
J SIMPLE	0	Delay Adjustable delay.
	1	TapeEcho Echo effect that simulates tape delay.
	2	AnalgDLY Simulated analog delay.
	3	PP Delay Ping Pong delay. Stereo output switches delay between left and right.
	4	Reverse Reverse delay creating a backwards effect.
	5	Hall Concert hall reverb. Size controlled by Decay.
	6	Room Room reverb. Natural sounding of a large room.
	7	Spring Spring reverb. Simulation of reverbs built into guitar amplifiers.
	8	Arena Huge reverb creating a large concert hall or arena effect.
9	TileRoom Tiled wall reverb. Loud with lots of decay.	



ZFX Tools Startup Guide

ZFX Tools is an application combining a number of useful functions. It includes a recorder that makes it easy to capture your instrument, a sound-coordinated rhythm machine that gives you a virtual drummer and bassist, an editor with an intuitive mouse-based interface, a librarian function for managing patches, and a precision tuner. In addition, a search function lets you download the latest patches or rhythms and access a vast assortment of preset patches and rhythm patterns. This Startup Guide explains how to install ZFX Tools on your computer. The steps for recording while playing rhythm patterns are also explained.

For Users of Windows Vista/XP

1 Insert the Install Disc and click on "ZFX Tools 1. * . * . * Setup.exe" in the "Windows" folder to start the installer.

2 Select the setup language and click [OK].

3 The installation wizard starts up. Click [Next] to begin the installation.

4 The "Software License Agreement" screen appears.



Read the agreement and check the "I accept the terms in the license agreement" radio button to confirm your acceptance of the agreement. Then click [Next].

5 A warning message appears.



Do not yet connect the USB cable at this point.

6 Select the installation target folder.

To accept the default installation target folder, click [Next]. To select a different folder, click [Change].

* If you do not want a shortcut to be created on the Desktop, remove the check mark from the box.

7 Click [Install] to start the installation.

ZFX Tools will be installed. Next, proceed to the installation of the driver software.

Driver Installation

1 The ZOOM G Series Audio Driver installation wizard appears



Click [Next].

* If the driver install wizard window is not visible, click on "ZOOM G Series Audio Driver" in the task bar.

2 License Agreement



The License Agreement is displayed. Read the agreement and place a check mark in the "I accept the terms in the License Agreement" box to confirm your acceptance of the agreement. Then click [Next].

3 Choose Start Menu Folder

You can specify the destination folder where the shortcut to uninstall/repair the driver will be located. Normally, simply click [Install].

4 Welcome to ZOOM Driver Setup!



A dialog box such as shown here will appear three times. Click [Next] every time to proceed.

If a software installation warning dialog box is shown, click [Continue].

If a Windows Security message indicating that the driver software publisher cannot be verified appears, click [Install this driver].

* In this case, the message "ZOOM G Series Audio Driver (Not Responding)" may appear, but this is not a problem. Wait until the driver responds.

5 Please plug in the device now



When the "Please plug in the device now" dialog box appears, connect the unit and the computer with the USB cable and click [Next].

6 Standard driver installation

When you connect the unit to the computer, a dialog box for installing the standard driver appears.

- **When using Windows XP**
→ When the message "Welcome to the Hardware Update Wizard" appears, select "Install the software automatically" and click [Next] to complete the process.
- **When using Windows Vista**
→ Select "Locate and install driver software" and click [Continue] to complete the process.

When the installation of the standard driver for your operating system has completed, return to "ZOOM G Series Audio Driver" and click [Next].

7 ZOOM G Series Audio Driver installation

If a warning message to confirm Hardware installation appears, click [Continue Anyway]. Click [Finish] to complete the installation.


For Users of MacOS X

1 Insert the Install Disc and click on "ZFX Tools 1. * . * . * Setup.mpkg" in the "MacOS X" folder to start the installer.

* Before the Installer starts, a dialog box may be displayed. Click [Continue].

2 The Installer starts, and the "Introduction" screen appears. Click [Continue].

3 The "Software License Agreement" screen appears. Read the information carefully and then click [Continue].



* When you click [Continue], a confirmation dialog box appears. Click [Agree] to continue.

4 The "Installation Destination" screen appears. Click [Continue].




* The installation destination for ZFX Tools cannot be changed.
* This screen appears only under OS X 10.4, not under OS X 10.5.

5 The ZFX Tools "Standard Installation" screen appears. Click [Install].



6 The password entry dialog box appears. Enter the name and password of a user with administrator privileges, and click [OK].



* When you click [OK], the installation confirmation dialog box appears again. Click [Continue installation].

7 Click [Restart] to complete the installation.




Installation precautions

- You must have Administrator privileges to install the software. If your user level does not provide this, please contact your system administrator.
- Before starting the installation, shut down all other applications.
- Before starting the installation, disconnect the USB cable between the G1u and the computer.
- When installation is complete, a restart of the computer may be necessary.

ZFX Tools Startup Guide

Startup

Connect the G1u to the computer



When you connect the G1u to the computer, ZFX Tools starts up automatically, and the main screen such as shown below appears.

→ If ZFX Tools does not start automatically, you can start the application as follows.

- **Windows:** Double-click the "ZFX Tools" shortcut that was created on the Desktop.
- **MacOS X:** Open the "Applications" folder and then the "ZFX Tools" folder, and double-click "ZFX Tools.app".

Search & Librarian area

Serves for patch and rhythm management, searching, downloading and other functions. The tuner is also shown in this area.

Tool Set area

Serves for managing settings for the various functions of ZFX Tools as "Tool Sets". The master level is also adjusted here.

Main screen



Editor area

Serves for editing the currently selected patch.


Recording area

Serves for recording/playback of your instrument, rhythm playback etc.

→ For details on each area, please refer to the PDF Manual.

Recording an Instrument

1 Use the search function to find a patch and rhythm pattern




Click the [Search] button to bring up the search screen.

You can use word search to find sound settings by association. For example, if you enter "Rock" in the search field, results such as shown below will appear.



2 Select a patch



Next to the patch name, a "sound chart" indicates the sound character of the patch. Use this as reference when selecting patches. When you have decided on the patch to use for recording, click the [LOAD] button to load the patch into the G1u.

3 Select a rhythm pattern



By clicking the [PREVIEW] icon, you can check how the rhythm pattern sounds. When you have decided on the rhythm pattern to use for recording, click the [LOAD] button to load the rhythm into the rhythm machine.

4 Start to record

Click the [Record] button and then the [Play] button in the Recording area to start recording while playing the selected rhythm pattern as a backing.




(1) [Record] button (2) [Play] button

5 Check the result

When you have finished recording, click the [Play] button to check the result.



Starting over




When you click the left-pointing arrow next to the [TAKE] icon, the recorder returns to the condition before the current recording.

6 Save the result

When you are satisfied with the recording, save the Tool Set. Clicking the [SAVE] button in the Tool Set area saves the current recorder settings, rhythm machine settings, and edited effect information as a Tool Set.



Saving as audio data



Open the File menu and select "Mix Down". The recorded instrument sound and the rhythm sound will be mixed and saved as audio data.

Operating environment

Windows XP (SP2) or later / Windows Vista or later
 Pentium 4 1.4 GHz or higher / Athlon XP or higher
 512 MB RAM (1 GB or more recommended)
 1024 x 600 or better screen resolution
 USB 1.1 or 2.0 compatible port
 64-bit operating systems are not supported.
 * Do not use a USB hub.

Mac OS X 10.4.6 or later / 10.5 or later
 Intel Core Duo processor 1.66 GHz or higher (Intel Mac only)
 512 MB RAM (1 GB or more recommended)
 1024 x 600 or better monitor resolution
 USB 1.1 or 2.0 compatible port

* Do not use a USB hub.

Trademark information

* Microsoft, Windows XP and Windows Vista are registered trademarks of Microsoft Corporation in the U.S.A. and in other countries.
 * Mac, the Mac Logo, Mac OS, and Apple are registered trademarks of Apple Inc. in the U.S.A. and in other countries.
 * Intel, Pentium, and Core are registered trademarks of Intel Corporation.

* AMD and Athlon are registered trademarks of Advanced Micro Devices, Inc.
 * All other trademarks, product names, and company names are the property of their respective owners.
 * Trademarks and registered trademarks mentioned in this document are used only to indicate sonic characteristics and do not indicate any affiliation with ZOOM Corporation.

For support, contact:

ZOOM
 ZOOM CORPORATION

4-4-3 Kanda-surugadai, Chiyoda-ku, Tokyo
 101-0062, Japan
 Web Site: <http://www.zoom.co.jp/>

Planning and development by:

SONICWARE
 SONICWARE Ltd.

2-26-17 Higashi-ikebukuro,
 Toshima-ku, Tokyo 170-0013, Japan
 Web Site: <http://www.sonicware.jp/>

Ableton Live Lite 7 ZOOM Edition Startup Guide

This guide explains how to install Ableton Live Lite 7 ZOOM Edition (hereafter simply called "Live Lite 7") on a computer, make connections and settings for this unit and record.

Live Lite 7 installation | Connections and preparation | Using Live Lite 7 to record | Windows Vista/XP

To connect this unit to a computer running Windows Vista (or Windows XP) and to enable audio input/output, perform the following steps. The installation description uses Windows Vista as an example.

- 1 Insert the supplied Installation Disc (DVD-ROM) into the DVD drive of the computer, navigate to the "Windows" folder, and execute "G-Series_ASIO.exe" to install the driver.**

When the contents of the DVD-ROM are shown, open the "Windows" folder and use "G-Series_ASIO.exe" to start the installation process.



HINT


If ZFX Tools are already installed, there is no need to perform the driver installation steps.

- 2 Install Live Lite 7.**

To install Live Lite 7, insert the Installation Disc and click on "Setup.exe" of the "ableton_live_7017_zoom_win" in the "Windows" folder.



- 3 Connect G1u to the computer using a USB cable.**




NOTE

- If the ZFX Tools are installed, the tools application will start up when you connect the USB cable. To use Live Lite 7, you should first terminate ZFX Tools.
- Use a high-quality USB cable and keep the connection as short as possible. If USB bus power is supplied to this unit via a USB cable that is more than 3 meters in length, the low voltage warning indication may appear.

- 4 Bring up the "Sound" window from the Control Panel and select the input device setting for the computer.**


To bring up the "Sound" window, select "Control Panel" from the Start menu, click "Hardware and Sound", and then click "Sound".



In the "Sound" window, verify that "G Series Audio" is listed under playback/recording devices, and that the entry is checked. (To switch between playback and recording devices, click the tabs at the top of the window.)

If "G Series Audio" is not shown with a check mark, right-click on the icon for the device and click "Set Default" so that a check mark appears.

- 5 Start Live Lite 7. Then access the "Options" menu, select "Preferences", and make the settings for the Audio Device.**



You can use the slider to adjust latency for the ASIO driver.

The latency should be set to a value that is as low as possible without causing sound dropouts during recording and playback.

When the setting is complete, close the respective windows.

HINT

During initial startup, a prompt for entering the serial number will appear. The number can be found on the supplied "Upgrade & Unlock Card".

NOTE

- To perform the online unlocking procedure, the computer must be connected to the Internet.
- If the computer is not connected to the Internet, the program can only be used as a trial version.

Continued overleaf

Ableton Live Lite 7 ZOOM Edition Startup Guide

Live Lite 7 installation | Connections and preparation | Using Live Lite 7 to record | Mac OS X

To connect this unit to a computer running Mac OS X and to enable audio input/output, perform the following steps.

- 1 Insert the supplied Installation Disc (DVD-ROM) into the DVD drive of the Macintosh computer.**


The contents of the DVD-ROM appear automatically. If nothing happens when you insert the DVD-ROM, double-click the "Installation Disc" icon shown on the desktop.

- 2 Install Live Lite 7.**

To install Live Lite 7, insert the Installation Disc and click on "ableton_live_7017_zoom_mac.pkg" in the "MacOS X" folder.



- 3 Connect G1u to the computer using a USB cable.**



NOTE

- If the ZFX Tools are installed, the tools application will start up when you connect the USB cable. To use Live Lite 7, you should first terminate ZFX Tools.
- Use a high-quality USB cable and keep the connection as short as possible. If USB bus power is supplied to this unit via a USB cable that is more than 3 meters in length, the low voltage warning indication may appear.

- 4 From the "Applications" folder, open the "Utilities" folder and double-click on "Audio MIDI Setup".**


The "Audio MIDI Setup" screen appears. Click on "Audio Devices" and verify that "USB Audio CODEC" is selected as Default Input and Default Output.




If another device is selected, use the pull-down menu to change the selection to "USB Audio CODEC".

When the setting is complete, close Audio MIDI Setup.

- 5 Start Live Lite 7. From the "Live" menu, select "Preferences" and then make the settings for the Audio Device.**



- Select "CoreAudio".
- Select "USB Audio CODEC (2in 0out)".



- Select "USB Audio CODEC (0in 2out)".

You can adjust latency by changing the buffer size.

The latency should be set to a value that is as low as possible without causing sound dropouts during recording and playback.

When the setting is complete, close the window.

HINT

During initial startup, a prompt for entering the serial number will appear. The number can be found on the supplied "Upgrade & Unlock Card".

NOTE

- To perform the online unlocking procedure, the computer must be connected to the Internet.
- If the computer is not connected to the Internet, the program can only be used as a trial version.

Continued overleaf

6 From the "File" menu of Live Lite 7, select "New Live Set".



When you execute "New Live Set", the following Live Set is created.



↑Session View

HINT

To add a track, right-click in the "Clip/Devices Drop Area" and use the menu that appears.


NOTE

There are two views for the Live Set: Session View and Arrangement View. The initial setting is Session View. This view serves as a scratch pad for music, letting you freely improvise and arrange ideas.

7 Connect the guitar to the Input jack of the G1u and select an effect patch.




8 Click the Arm button of the track on which you want to record so that the track is ready to record.



Arm button

9 Adjust the track recording level while playing your instrument.

To obtain the optimum recording level, turn up the master volume control on the G1u until just before the level meter registers in red.



Track activator Level meter

10 When the recording level setting is complete, turn the track activator off.

The level meter is now shown in gray and the signal returned to the G1u via the computer is muted.

NOTE

If the track activator is on, the G1u output and the monitoring signal of the computer will be output simultaneously, which may cause a flanger-like effect in the sound.

11 Click the Arrangement View selector to switch to Arrangement View.



Arrangement View selector

Clicking on the Arrangement View selector switches from Session View to Arrangement View.



↑Arrangement View

NOTE

The Arrangement View lets you perform general recording, arranging, editing and other tasks on a timeline.

12 To start recording, first click the Record button to set the application to the recording standby mode. You can then start recording by clicking the Play button.



Play button Record button


13 Check the recorded content.

To play the recording, perform the following steps.



1. Click the Session View selector to change to Session View.

2. Turn the track activator on.



3. Move the master channel fader down.

6. Raise the fader to obtain a suitable volume.

4. Double-click the Stop button to move the song position to the beginning.



5. Click the Play button to start playback of the recorded content.

Using the application together with ZFX Tools

To access the ZFX Tools Editor and Librarian functions while using Live Lite 7, proceed as follows.

- 1 Start ZFX Tools first.
- 2 Access "Connect" from the menu and cancel the connect setting of ZFX Tools and the G1u.



HINT

Leave the USB cable connected.

- 3 While ZFX Tools is running, start Live Lite 7.

NOTE

There is no need to change any settings in Live Lite 7.

For optimum performance

While using Live Lite 7, other applications may sometimes slow down notably or become unstable. If this happens frequently, consider taking the following steps to optimize the operation conditions for Live Lite 7.

- 1 Shut down other applications besides Live Lite 7. In particular, check for resident software and other utilities.
- 2 Reduce the number of plug-ins (effects, instruments) used by Live Lite 7.

When there is a high number of plug-ins, the computer's processing power may not be able to keep up. Reducing the number of tracks for simultaneous playback can also be helpful.

If applications still run very slowly or the computer itself does not function properly, disconnect the G1u from the computer and shut down Live Lite 7. Then reconnect the USB cable and start Live Lite 7 again.

Trademark information

- * Microsoft, Windows XP and Windows Vista are registered trademarks of Microsoft Corporation in the U.S.A. and in other countries.
- * Mac OS and Core Audio are registered trademarks of Apple Inc. in the U.S.A. and in other countries.
- * Ableton and Ableton Live are registered trademarks of Ableton AG.
- * ASIO is a registered trademark of Steinberg Soft- and Hardware GmbH.
- * MIDI is a registered trademark of the AMEI (Association of Musical Electronics Industry).

This guide explains how to install Ableton Live Lite 8 ZOOM Edition (hereafter simply called "Live Lite 8") on a computer, make connections and settings for this unit and record.

Live Lite 8 installation

Connections and preparation

Using Live Lite 8 to record

Windows

To connect this unit to a computer running Windows and to enable audio input/output, perform the following steps. The installation description uses Windows Vista as an example.

- 1 **Insert the supplied Installation Disc (DVD-ROM) into the DVD drive of the computer, navigate to the "Windows" folder, and execute "G-Series_ASIO.exe" to install the driver.**

When the contents of the DVD-ROM are shown, open the "Windows" folder and use "G-Series_ASIO.exe" to start the installation process.



HINT


If ZFX Tools are already installed, there is no need to perform the driver installation steps.

- 2 **Install Live Lite 8.**

To install Live Lite 8, insert the Installation Disc and click on "Setup.exe" of the "Live_808_Zoom_Installer_Win" in the "Windows" folder.



- 3 **Connect G1u to the computer using a USB cable.**




NOTE

- If the ZFX Tools are installed, the tools application will start up when you connect the USB cable. To use Live Lite 8, you should first terminate ZFX Tools.
- Use a high-quality USB cable and keep the connection as short as possible. If USB bus power is supplied to this unit via a USB cable that is more than 3 meters in length, the low voltage warning indication may appear.

- 4 **Bring up the "Sound" window from the Control Panel and select the input device setting for the computer.**

To bring up the "Sound" window, select "Control Panel" from the Start menu, click "Hardware and Sound", and then click "Sound".




In the "Sound" window, verify that "G Series Audio" is listed under playback/recording devices, and that the entry is checked. (To switch between playback and recording devices, click the tabs at the top of the window.)


If "G Series Audio" is not shown with a check mark, right-click on the icon for the device and click "Set Default" so that a check mark appears.

- 5 **Start Live Lite 8. Then access the "Options" menu, select "Preferences", and make the settings for the Audio Device.**

1. Select "ASIO". 2. Select "ZOOM G Series ASIO".



3. Click on "Hardware Setup".



You can use the slider to adjust latency for the ASIO driver.

The latency should be set to a value that is as low as possible without causing sound dropouts during recording and playback.

When the setting is complete, close the respective windows.

HINT

The serial number that must be input when starting the program for the first time can be found on the supplied "Live Lite" card.

NOTE

- To perform "Authorize with ableton.com", the computer must be connected to the Internet.
- If the computer is not connected to the Internet, use another computer connected to the Internet to authorize the program. Otherwise the program can only be used as a trial version.

Continued overleaf

Live Lite 8 installation

Connections and preparation

Using Live Lite 8 to record

Live Lite 8 installation

Connections and preparation

Using Live Lite 8 to record

Mac OS X


To connect this unit to a computer running Mac OSX and to enable audio input/output, perform the following steps.

- 1 **Insert the supplied Installation Disc (DVD-ROM) into the DVD drive of the Macintosh computer.**


The contents of the DVD-ROM appear automatically. If nothing happens when you insert the DVD-ROM, double-click the "Installation Disc" icon shown on the desktop.

- 2 **Install Live Lite 8.**

To install Live Lite 8, insert the Installation Disc and click on "Live_808_Zoom.mpkg" in the "MacOS X" folder.



- 3 **Connect G1u to the computer using a USB cable.**



NOTE

- If the ZFX Tools are installed, the tools application will start up when you connect the USB cable. To use Live Lite 8, you should first terminate ZFX Tools.
- Use a high-quality USB cable and keep the connection as short as possible. If USB bus power is supplied to this unit via a USB cable that is more than 3 meters in length, the low voltage warning indication may appear.


- 4 **From the "Applications" folder, open the "Utilities" folder and double-click on "Audio MIDI Setup".**

The "Audio MIDI Setup" screen appears. Click on "Audio Devices" and verify that "USB Audio CODEC" is selected as Default Input and Default Output.




If another device is selected, use the pull-down menu to change the selection to "USB Audio CODEC". When the setting is complete, close Audio MIDI Setup.

- 5 **Start Live Lite 8. From the "Live" menu, select "Preferences" and then make the settings for the Audio Device.**



1. Select "CoreAudio". 2. Select "USB Audio CODEC (2in 0out)".



3. Select "USB Audio CODEC (0in 2out)".

You can adjust latency by changing the buffer size.

The latency should be set to a value that is as low as possible without causing sound dropouts during recording and playback.

When the setting is complete, close the window.

HINT


The serial number that must be input when starting the program for the first time can be found on the supplied "Live Lite" card.

NOTE

- To perform "Authorize with ableton.com", the computer must be connected to the Internet.
- If the computer is not connected to the Internet, use another computer connected to the Internet to authorize the program. Otherwise the program can only be used as a trial version.

Continued overleaf

6 From the "File" menu of Live Lite 8, select "New Live Set".



When you execute "New Live Set", the following Live Set is created.



↑Session View

HINT

To add a track, right-click in the "Clip/Devices Drop Area" and use the menu that appears.


NOTE

There are two views for the Live Set: Session View and Arrangement View. The initial setting is Session View. This view serves as a scratch pad for music, letting you freely improvise and arrange ideas.

7 Connect the guitar to the Input jack of the G1u and select an effect patch.




8 Click the Arm button of the track on which you want to record so that the track is ready to record.



Arm button

9 Adjust the track recording level while playing your instrument.

To obtain the optimum recording level, turn up the master volume control on the G1u until just before the level meter registers in red.



Track activator Level meter

10 When the recording level setting is complete, turn the track activator off.

The level meter is now shown in gray and the signal returned to the G1u via the computer is muted.

NOTE

If the track activator is on, the G1u output and the monitoring signal of the computer will be output simultaneously, which may cause a flanger-like effect in the sound.

11 Click the Arrangement View selector to switch to Arrangement View.



Arrangement View selector

Clicking on the Arrangement View selector switches from Session View to Arrangement View.



↑Arrangement View

NOTE

The Arrangement View lets you perform general recording, arranging, editing and other tasks on a timeline.

12 To start recording, first click the Record button to set the application to the recording standby mode. You can then start recording by clicking the Play button.



Play button Record button


13 Check the recorded content.

To play the recording, perform the following steps.

1. Click the Session View selector to change to Session View.



2. Turn the track activator on.



3. Move the master channel fader down.

6. Raise the fader to obtain a suitable volume.

4. Double-click the Stop button to move the song position to the beginning.



5. Click the Play button to start playback of the recorded content.

Trademark information

- * Microsoft, Windows and Windows Vista are registered trademarks of Microsoft Corporation in the U.S.A. and in other countries.
- * Mac OS and Core Audio are registered trademarks of Apple Inc. in the U.S.A. and in other countries.
- * Ableton and Ableton Live are registered trademarks of Ableton AG.
- * ASIO is a registered trademark of Steinberg Soft- and Hardware GmbH.
- * MIDI is a registered trademark of the AMEI (Association of Musical Electronics Industry).

Using the application together with ZFX Tools

To access the ZFX Tools Editor and Librarian functions while using Live Lite 8, proceed as follows.

1 Start ZFX Tools first.

2 Access "Connect" from the menu and cancel the connect setting of ZFX Tools and the G1u.



HINT

Leave the USB cable connected.

3 While ZFX Tools is running, start Live Lite 8.

NOTE

There is no need to change any settings in Live Lite 8.

For optimum performance

While using Live Lite 8, other applications may sometimes slow down notably or become unstable. If this happens frequently, consider taking the following steps to optimize the operation conditions for Live Lite 8.

1 Shut down other applications besides Live Lite 8.

In particular, check for resident software and other utilities.

2 Reduce the number of plug-ins (effects, instruments) used by Live Lite 8.

When there is a high number of plug-ins, the computer's processing power may not be able to keep up. Reducing the number of tracks for simultaneous playback can also be helpful.

If applications still run very slowly or the computer itself does not function properly, disconnect the G1u from the computer and shut down Live Lite 8. Then reconnect the USB cable and start Live Lite 8 again.