



# Firmware Upgrade Guide

Instamic Pro Plus and Plus C

Firmware version 2.3.49

© 2025 Instamic, Inc.

Copying or reprinting this manual in part or in whole without permission is prohibited.

Proper display not possible on grayscale devices.

## Release Notes:

- Fixed a bug when using odd frame rates values (23.98 and 29.97) with Atomos and Tentacle external sync modes.

## Introduction

### You will need:



Windows or macOS Computer  
with Internet Access



USB-C Cable



Instamic Pro Plus or Plus C

### Firmware update process:


1. Download the Instamic Firmware Upgrade application.
2. Extract the ZIP File.
3. Run the Instamic Firmware Upgrade application.
4. Follow the on-screen directions.
5. Confirm that the firmware of your Instamic has been updated correctly.

# Upgrading the Firmware

*This guide explains the firmware upgrade to version 2.3.46 as an example.*

## 1. Download the Firmware Upgrade application file.


Download Firmware Upgrade app (zip) from the [Instamic support and downloads page](#):




## On Windows

### 2. Extract the ZIP file:

Select the folder that contains the downloaded ZIP file. Click ① "Compressed Folder Tools" and then click ② "Extract all". ③ Double-click the .exe file to run the app.







## On macOS


### 2. Extract the ZIP file:

After downloading, open the ① "Downloads" folder which appears at the right end of the macOS dock by default. Then, click ② Instamic\_Pro\_Plus\_Firmware\_Upgrade\_Tool\_2.8.3\_macOS.zip. Downloaded files will be shown.




### 3. Launch the Instamic Firmware Upgrade app.

Wait until the latest firmware version appears under Firmware Upgrade Pro Plus:




### 4. Connect the Instamic using the provided USB cable.


If possible, disconnect any other USB external devices. The first of three  will appear:




### 5. Press and hold the Instamic Power button until the top two LEDs turn off, then release.



## 6. Instamic will disconnect from your computer.


- Let the app do its magic (do not disconnect the unit while the Loading bar is on).
- Your Instamic will boot up again, and three  will confirm that you have successfully updated your device. This is how the application looks when you have successfully upgraded your unit.



## Confirm the Firmware was updated

### 1. Launch the Remote app and connect to your Instamic.

The firmware version appears just below the Instamic icon.



# Troubleshooting and Solutions

## 1. Instamic reboots when you release the button after both LEDs go off.

- Turn on the Instamic.
- Connect it to your computer using the Instamic cable.
- Ensure it is correctly recognized by your computer as external storage.
- Launch the Firmware Upgrade application.
- Verify that a .txt file is stored in Instamic's internal memory.
- Press and hold the button on the Instamic until the top two green lights turn off.
- Do not disconnect your Instamic when the Loading bar comes out.
- The Instamic restarts with the latest firmware.

## 2. The first green check doesn't appear.

- Ensure that the Instamic internal storage is named INSTAMIC.
- Use the provided Instamic cable.
- Disconnect any devices with internal memory, such as a notebook, tablet, or similar.
- Reboot your computer, launch the app, and connect the Instamic.

## 3. The first green check appears only when I unplug the unit.

- Make sure the Instamic internal storage is labeled INSTAMIC.
- If it has a different name rename it using the right-click menu in Finder or the Format Memory application on Windows, or Disk Utility on Mac.

## 4. Your Instamic doesn't turn back on.

- Wait 3 hours. Do not charge your Instamic.
- Launch the Instamic Firmware Upgrade application.
- Connect the Instamic using the provided USB cable.
- Wait for 30 seconds until the Instamic reloads.

## 5. The application crashes immediately when I connect the Instamic.

Disconnect all USB devices and plug in only the Instamic.

**For any other questions, please contact us at [support@instamic.io](mailto:support@instamic.io).**

**instamic**

Instamic, Inc.

4-4-3 Kanda-surugadai, Chiyoda-ku, Tokyo 101-0062 Japan

[zoomcorp.com](http://zoomcorp.com)