

G1_{FOUR}/G1X_{FOUR} B1_{FOUR}/B1X_{FOUR}

Version 2.0 Supplementary Manual


The following functions have been added and changed in firmware version 2.0.


Changing the looper position

The looper can now be placed either before or after the effect. By changing the looper position to before the effect, the looped sound of a performance can be used to craft the sound without continuing to play.


1. Activate the looper.

• Press  **LOOPER**

Return to previous mode: Press  **LOOPER**



2. Change the looper position.

• Turn 

LOOPER			
Time	Stop	Mode	POST VOL
Jx2	Finish	Pre	80

Setting	Explanation
Pre	The looper is positioned before the effects.
Post	The looper is positioned after the effects.

NOTE

Changing the recording time, loop or position or tempo will clear any loop that has been recorded.

HINT

The tempo (BPM) setting available up to firmware version 1.1 can be changed using the rhythm or from SETTING > SETUP.

Setting value display during rhythm playback

Rhythm settings can now also be checked during rhythm playback.

Before Version 1.1

RHYTHM			
PATTERN	Count	BPM	VOL
GUIDE	ON	120	80

Stopped

RHYTHM			
			

Playing

After Version 2.0

RHYTHM			
PATTERN	Count	BPM	VOL
GUIDE	ON	120	80

Playing/stopped