

ZOOM Q4 Web Cam Audio Driver Installation Guide

(Mac)

Copyright(C) 2015 ZOOM Corporation. All Rights Reserved.

● Zoom Corporation does not bear liability for any damages or third-party claims arising from the use of the software, whether directly or indirectly. Unauthorized redistribution, sale, leasing, renting, alteration, or reverse engineering of the software is prohibited. Features and specifications of the software and the contents of the documentation may be changed in future without notice.

The actual content of screens and messages on the computer may differ from the illustrations used in this manual.

<Contents>

Introduction.....	2
Operation Environment Requirements	2
Precautions	2
Updating the driver	2
Installation	3
Uninstallation	5

Introduction

Thank you for downloading the ZOOM Q4 Web Cam Audio Driver.
This document describes how to install and uninstall the driver.

Operation Environment Requirements

Operating system: Mac OS X 10.8.5 or later/ 10.9.5 or later
/ 10.10.4 or later / 10.11 or later

Precautions

- 1) Start installation and uninstallation disconnecting Q4 from Macintosh.**
- 2) Before starting this application, shut down all other applications that are running.**

Updating the driver

Even if ZOOM Q4 Web Cam Audio Driver is already installed, new driver can be installed by following the procedure of installation.


Installation

1. Start Macintosh without any USB devices including Q4 (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Double-click on the "ZOOM Q4WebCamAudio.pkg" icon.




ZOOM
Q4WebC...udio.pkg


4. To start the installation, click [Continue].




5. Click [Install].



6. Click [Continue Installation].




7. Input password, if required.



Next, Progress bar will be displayed.

8. Completion of installation

Driver installation has been completed. Click [Restart] to close the installer and reboot Macintosh.




Uninstallation


1. Start Macintosh without any USB devices including Q4 (Except keyboard and mouse).
2. Shut down any applications that are running.
3. Double-click on the "ZOOM Q4WebCamAudioUninstaller" icon.



4. The uninstallation process starts. Confirm that you want to proceed by clicking [Uninstall]. To cancel the process, click [Cancel].



5. Input password, if required.



6. Completion of uninstallation

Driver uninstallation has been completed. Click [Restart] to close the uninstaller and reboot Macintosh.

