

Software Confirmed for Use with ZOOM iOS Microphones

As of August 2025, software that have been tested with iOS Microphone products.

'O' Compatible.

'∆' Under testing.

x' Not Compatible.

iOS 18

	Model	Camera GarageBand		Mobile HandyShare	HandyRecorder		Twitch	iMovie
		(Pre-installed apps)			Pro			
			2.3	1.3	5.6	5.4		3.0.5
	iQ6	0	0	0	0*	0*	0	0
	iQ7	0	0	0	0*	0*	0	0

^{*} An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

iOS 17

Madal	Camera GarageBand		Mobile HandyShare	HandyRecorder		Twitch	iMovie
Model	(Pre-installed apps)			Pro			
		2.3	1.2	5.4	5.2		3.0.3
iQ6	0	0	0	0*	O*	0	0
iQ7	0	0	0	0*	0*	0	0

^{&#}x27;*' An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

iPadOS 18

		Camera	GarageBand	Mobile HandyShare	HandyRecorder		Logic Pro	Twitch	iMovie
	Model	(Pre-installed apps)			Pro				
			2.3	1.3	5.6	5.4	2.1		3.0.5
	iQ6	0	0	0	0*	O*	×	0	0
	iQ7	0	0	0	0*	0*	×	0	0

^{&#}x27;*' An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

 $To use \ Mobile \ Handy \ Recorder \ (or \ Mobile \ Handy \ Recorder \ Pro) \ with \ an \ adapter, connect \ the \ iQ6/iQ7 \ before \ starting \ the \ app.$

iPadOS 17

Madal	Camera	GarageBand	Mobile HandyShare	HandyRecorder		Logic Pro	Twitch	iMovie
Model	(Pre-installed apps)			Pro				
		2.3	1.2	5.4	5.2	1.1		3.0.3
iQ6	0	0	0	0*	O*	0	0	0
iQ7	0	0	0	0*	O*	0	0	0

^{*} An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.