

Software Confirmed for Use with ZOOM iOS Microphones

As of July 2025, software that have been tested with iOS Microphone products.

'○' Compatible.

'△' Under testing.

×' Not Compatible.

iOS 18

| Model | Camera | GarageBand | Mobile HandyShare | HandyRecorder | | Twitch | Riverside | iMovie |
|-------|----------------------|------------|-------------------|---------------|-----|--------|-----------|--------|
| | (Pre-installed apps) | | | Pro | | | | |
| | | 2.3 | 1.3 | 5.6 | 5.4 | | | |
| iQ6 | ○ | ○ | ○ | ○* | ○* | △ | △ | △ |
| iQ7 | ○ | ○ | ○ | ○* | ○* | △ | △ | △ |

*' An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

iOS 17

| Model | Camera | GarageBand | Mobile HandyShare | HandyRecorder | | Twitch | iMovie |
|-------|----------------------|------------|-------------------|---------------|-----|--------|--------|
| | (Pre-installed apps) | | | Pro | | | |
| | | 2.3 | 1.2 | 5.4 | 5.2 | | 3.0.3 |
| iQ6 | ○ | ○ | ○ | ○* | ○* | ○ | ○ |
| iQ7 | ○ | ○ | ○ | ○* | ○* | ○ | ○ |

*' An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

iPadOS 18

| Model | Camera | GarageBand | Mobile HandyShare | HandyRecorder | | Logic Pro | Twitch | Riverside | iMovie |
|-------|----------------------|------------|-------------------|---------------|-----|-----------|--------|-----------|--------|
| | (Pre-installed apps) | | | Pro | | | | | |
| | | 2.3 | 1.3 | 5.6 | 5.4 | 2.1 | | | |
| iQ6 | ○ | ○ | ○ | ○* | ○* | × | △ | △ | △ |
| iQ7 | ○ | ○ | ○ | ○* | ○* | × | △ | △ | △ |

*' An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

iPadOS 17

| Model | Camera | GarageBand | Mobile HandyShare | HandyRecorder | | Logic Pro | Twitch | iMovie |
|-------|----------------------|------------|-------------------|---------------|-----|-----------|--------|--------|
| | (Pre-installed apps) | | | Pro | | | | |
| | | 2.3 | 1.2 | 5.4 | 5.2 | 1.1 | | 3.0.3 |
| iQ6 | ○ | ○ | ○ | ○* | ○* | ○ | ○ | ○ |
| iQ7 | ○ | ○ | ○ | ○* | ○* | ○ | ○ | ○ |

*' An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.