

# Software Confirmed for Use with ZOOM iOS Microphones

As of March 2025, software that have been tested with iOS Microphone products.

'○' Compatible.

'△' Under testing.

'×' Not Compatible.

## iOS 18

Model	Camera	GarageBand	Mobile HandyShare	HandyRecorder		Twitch	Riverside	iMovie
	(Pre-installed apps)			Pro			(Spotify for Creators)	
		2.3	1.3	5.6	5.4			
iQ6	△	○	○	○*	○*	△	△	△
iQ7	△	○	○	○*	○*	△	△	△

\* An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

## iOS 17

Model	Camera	GarageBand	Mobile HandyShare	HandyRecorder		Twitch	Riverside	iMovie
	(Pre-installed apps)			Pro			(Spotify for Creators)	
		2.3	1.2	5.4	5.2			3.0.3
iQ6	○	○	○	○*	○*	○	△	○
iQ7	○	○	○	○*	○*	○	△	○

\* An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

## iPadOS 18

Model	Camera	GarageBand	Mobile HandyShare	HandyRecorder		Logic Pro	Twitch	Riverside	iMovie
	(Pre-installed apps)			Pro				(Spotify for Creators)	
		2.3	1.3	5.6	5.4				
iQ6	△	○	○	○*	○*	△	△	△	△
iQ7	△	○	○	○*	○*	△	△	△	△

\* An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.

## iPadOS 17

Model	Camera	GarageBand	Mobile HandyShare	HandyRecorder		Logic Pro	Twitch	Riverside	iMovie
	(Pre-installed apps)			Pro				(Spotify for Creators)	
		2.3	1.2	5.4	5.2	1.1			3.0.3
iQ6	○	○	○	○*	○*	○	○	△	○
iQ7	○	○	○	○*	○*	○	○	△	○

\* An adapter is necessary to connect an iQ6/iQ7 to an iPhone/iPad that has a USB-C connector.

To use Mobile Handy Recorder (or Mobile Handy Recorder Pro) with an adapter, connect the iQ6/iQ7 before starting the app.