

## USB mics confirmed to work with the P2

USB mics that are not included in the list below can be used with the P2, but be aware of the following limitations.

- Mics that consume high amounts of power, including those with RGB lighting, might not be usable.\*
- The amount the level changes when the INPUT LEVEL knob on the P2 is operated depends on the mic.
- If a mic has special functions, they might not be usable.

\*If the combined power consumption of the two connected USB mics exceeds 700mA, the P2 will stop operating.

Brand	Model name	Remarks
AKG	LYRA	The level will rise to the maximum once when the P2 INPUT LEVEL knob is turned to around 8 – 9 o'clock.
Audio Technica	AT2020USBX	
Audio Technica	AT2040USB	
ELECOM	HS-MC05UBK	
ELECOM	HS-NB03SUBK	
ELECOM	USB-AADC01BK	
ELECOM	HS-MC09UBK	
Elgato	Wave:3	
HORI	Karaoke mic for Nintendo Switch	
HyperX	SoloCast	Noise could occur when being used at the same time as another mic.
HyperX	QuadCast S	To make the mic LED light, connect it after turning on the P2.
JBL	QUANTUM STREAM STUDIO USB	
JBL	QUANTUM STREAM USB	
Logicool G	Blue Yeti	
MAONO	DM30 RGB	The mic mute function cannot be used.
Razer	Seiren Mini USB	
RØDE	NT1GEN5	
RØDE	PodMic USB	Noise might occur when connected in rare cases. If noise occurs, reconnect the USB cable.
Roland	GO:PODCAST	
SABRENT	AU-MMSA	
SAMSON	Q2U	
Sennheiser	Profile USB Microphone	
SHURE	MV6	To maximize utilization of the P2 functions, disable Auto-level, Real-time Denoiser and Popper Stopper. When using an MV6 with another mic, confirm that the P2 has recognized the connected MV6 before connecting the other mic.
SHURE	MV7	
SONY	ECM-PCV80U	
THRONMAX	Mdrill One Pro	
TONOR	TC-777	
UGREEN	External USB Sound Card (30724)	
YAMAHA	AG01	Power must be supplied from an external adapter.
ZealSound	K66	
ZOOM	ZUM-2	