

L6max

LiveTrak



Version 1.1 Supplementary Manual

You must read the Usage and Safety Precautions before use.

©2025 ZOOM CORPORATION

Copying or reprinting this manual in part or in whole without permission is prohibited.

Product names, registered trademarks and company names in this document are the property of their respective companies. All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

Proper display is not possible on grayscale devices.

Contents

- Functions added in Version 1.1..... 3
 - Adjusting the USB output level in audio interface mode..... 3
 - Applying internal effects to the SUB-MIX / MIX MINUS.....5
 - Block diagram.....7
- Notes about this manual..... 8

Functions added in Version 1.1

Adjusting the USB output level in audio interface mode

The individual track levels output to the computer, smartphone or tablet can be adjusted.

1. Press  (Operation button 1) on the Home Screen.
This opens the Menu Screen.



2. Use  (operation button 2) and  (operation button 3) to select "USB Audio Interface", and press  (operation button 4) to confirm.



3. Use  (operation button 2) and  (operation button 3) to select "Send Level", and press  (operation button 4) to confirm.



4. Use  (operation button 2) and  (operation button 3) to select the track to set, and press  (operation button 4) to confirm.



5. Use  (operation button 2) and  (operation button 3) to set the parameter value, and press  (operation button 4) to confirm.

This parameter can be set to “Mute” or from –40 to +40 dB.



NOTE


- These settings are enabled when USB audio is set to “Multi Track”.
- The MASTER track is output by USB with its post-fader level.

Applying internal effects to the SUB-MIX / MIX MINUS

Reverb and other internal effects can also be applied to the SUB-MIX and MIX MINUS.

1. Press  (Operation button 1) on the Home Screen.

This opens the Menu Screen.




2. Use  (operation button 2) and  (operation button 3) to select "Mixer", and press  (operation button 4) to confirm.




3. Use  (operation button 2) and  (operation button 3) to select "Effect Return", and press  (operation button 4) to confirm.



4. Use  (operation button 2) and  (operation button 3) to select "Sub-Mix" or "Mix Minus", and press  (operation button 4) to confirm.




5. Use  (operation button 2) and  (operation button 3) to select the setting, and press  (operation button 4) to confirm.



NOTE

- AI Noise Reduction cannot be used with these.
- When using an effect with MIX MINUS, set the effect send level for channel 7 (USB 1-2) to zero. Mix minus is not applied to the effect sound.

Block diagram



Notes about this manual

- USB Type-C is a trademark of the USB Implementers Forum.
- Recording from copyrighted sources, including CDs, records, tapes, live performances, video works and broadcasts, without permission of the copyright holder for any purpose other than personal use is prohibited by law. ZOOM CORPORATION will not assume any responsibility related to infringements of copyrights.



ZOOM CORPORATION

4-4-3 Kanda-surugadai, Chiyoda-ku, Tokyo 101-0062 Japan

zoomcorp.com