


# H4essential

## Handy Recorder



## Version 1.2 Supplementary Manual

You must read the Usage and Safety Precautions before use.

©2024 ZOOM CORPORATION

Copying or reprinting this manual in part or in whole without permission is prohibited.

Product names, registered trademarks and company names in this document are the property of their respective companies. All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.


Proper display is not possible on grayscale devices.

# Function added since Version 1.1

---

## ■ Functions added in Version 1.2

- Pause recording function added

A function has been added that enables recording to be paused by pressing .

## ■ Function added in Version 1.1

- Function added to turn the guide sound on/off with a shortcut

A function has been added that enables the guide sound to be turned on/off immediately by pressing and

holding  .  
ENTER

# Contents


---

- Function added since Version 1.1.....2
- Pausing recording.....4
- Turning the guide sound on/off with a shortcut..... 5
  - Turning the guide sound on/off.....5
- Notes about this manual..... 6


# Pausing recording


---

By pausing recording and not recording unwanted intervals, microSD card capacity can be conserved.

1. Press  during recording.

This pauses recording.



Press  again to resume recording.


## NOTE


Resuming recording will automatically add a mark at that point.

# Turning the guide sound on/off with a shortcut

This function allows the guide sound to be turned on/off anytime to suit the use situation.

## Turning the guide sound on/off

1. When the HOME screen is open, press and hold  .  
ENTER



This turns on/off the guide sound.



Home Screen



A notification about the switch will be shown (and announced with the guide sound).

# Notes about this manual

---

- The microSD, microSDHC and microSDXC logos are trademarks.
- USB Type-C is a trademark of the USB Implementers Forum.
- Recording from copyrighted sources, including CDs, records, tapes, live performances, video works and broadcasts, without permission of the copyright holder for any purpose other than personal use is prohibited by law. Zoom Corporation will not assume any responsibility related to infringements of copyrights.



ZOOM CORPORATION

4-4-3 Kanda-surugadai, Chiyoda-ku, Tokyo 101-0062 Japan

[zoomcorp.com](https://zoomcorp.com)