

H3-VR Firmware Update Guide

Copyright (C) 2021 ZOOM Corporation. All Rights Reserved.

● ZOOM Corporation will bear no responsibility for any losses or third-party claims resulting from the use of this software. Moreover, distribution, sale, leasing, rental, alteration, and reverse engineering without permission of this software are prohibited. The specifications of this software and the contents of this document could be changed without notice in the future.

- Copying or reprinting this manual in part or in whole without permission is prohibited.
- Windows® is a trademark or registered trademark of Microsoft® Corporation.
- Mac® is a trademark or registered trademark of Apple Inc.
- Other product names, registered trademarks and company names in this document are the property of their respective companies.
- All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.
- Proper display is not possible on grayscale devices.
- The illustrations in these instructions might differ from actual screens.

This guide explains updating the firmware to version 2.10 as an example.

1. Download the firmware update file.

Download the ZIP file that contains the firmware update file from the H3-VR download page.



SOFTWARE



- H3-VR Firmware**
H3-VR System Version 2.10 (Released 02/06/2020)
- H/F Series Stereo ASIO Driver**
Windows 8/8.1/10 (Released 02/06/2020)
- H/F Series Multi-Track ASIO Driver**
Windows 8/8.1/10 (Released 08/04/2020)
- ZOOM Ambisonics Player | Windows**
Windows 8/8.1/10 (Released 02/06/2020)
- ZOOM Ambisonics Player | Mac**
Mac OS X 10.11 ~ 11 (Released 02/06/2020)

VIEW PRODUCT


On Windows

2. Extract the ZIP file.


Select the folder that contains the downloaded ZIP file. Click ① “Compressed Folder Tools” followed by ② “Extract all”. This extracts the ZIP file.



3. Copy the firmware update file to a microSD card.
Copy the “H3VRSYSTEM.BIN” file to a microSD card.



Firmware update file




Copy the firmware update file to a microSD card.

On macOS


2. Extract the file.

After downloading, open the ① “Downloads” folder, which appears at the right end of the Dock by default. Then, click ②. Downloaded files will be shown.



3. Copy the firmware update file to a microSD card.

Copy the “H3VRSYSTEM.BIN” file to a microSD card.



Firmware update file

Copy the firmware update file to a microSD card.

The following procedures are the same on both Windows and macOS.


4. Install new batteries in the H3-VR or connect an AC adapter.

NOTE

Executing a firmware update is not possible if the remaining battery power is low.

5. Insert the microSD card into the H3-VR.

6. While pressing , turn the power on.



7. Use  and  to select "Update", and press .



This starts the firmware update.

NOTE

During the firmware update, do not turn the power off or remove the microSD card. Doing so could cause the H3-VR to become unstartable.

8. After the firmware update completes, turn the power off.




NOTE

In the unlikely event that a firmware update should fail, conduct the procedures from the beginning to update the firmware again.


Checking the firmware versions

1. Press .




This opens the Menu Screen.

2. Use  and  to select "System", and press .



3. Use  and  to select "Versions", and press .



4. Check the firmware versions.

