


MS-200D+

MULTISTOMP



Quick Tour


Software and documents related to this product can be viewed on the following website.




zoomcorp.com/help/ms-200dplus

You must read the Usage and Safety Precautions before use.


Installing batteries




A dedicated AC adapter (ZOOM AD-16) or a commercially-available portable USB battery can also be used.





Connecting equipment and turning the power on




Turning effects on/off





Adjusting effects





Press  to close the parameter screen.



When parameters are on multiple pages,  /  will be shown.



Replacing effects




Select



Confirm

Adding effects



Select



Confirm





Select an effect from the library and create an original sound.

Up to 2 effects can be combined freely using the MS-2000+.




The following message will appear when trying to add an effect that would exceed the maximum combination limit. Delete one effect before adding another one.





Changing the effect position shown



Deleting effects



Select





Execute



Switching patch memories


Patch memories store effect on/off states and parameter setting values. MS-200D+ effects are saved and recalled in units of patch memories. Up to 2 effects can be used in a single patch memory.




Use these to switch patch memories, enabling performance with various tones.



Using the tuner




Press and hold






TUNER Screen

The tuner cannot be used when the selected effect has a special function assigned, for example, effects that are on only while the footswitch is being pressed.

- Play an open string and adjust its pitch to tune it.
- The nearest note name and pitch detuning will be shown.




- ▶◀ will appear when the pitch is in tune.





















Use  to change tuner settings.

Output sound	BYPASS / MUTE
Standard pitch	430 Hz – 450 Hz
Tuner type	The desired tuner type can be selected.
Flat tuning	All strings can be tuned flat from an ordinary tuning by 1 (♭ 1), 2 (♭ 2) or 3 (♭ 3) semitones.

Using the MENU




MENU Screen

	Change the effect order.		Turn the preselect function on/off.
	Change the patch memory name.		The output sound on the LIBRARY Screen (when changing effects) can be set to either just the selected effect or the entire patch memory.
	Change effect routing.		Set the type of batteries.
	Set the footswitch function.		Set the backlight brightness.
	This restores a changed patch memory to the state it was in immediately after selection or to its factory default settings.		Adjust the display contrast.
	Copy a patch memory and save it in a different location.		Turn the ECO mode on/off.
	Create a new patch memory.		Restore the factory default settings.
	Delete a patch memory.		Check firmware versions.
	Adjust the overall volume.		Use a smartphone to scan a 2D code and access detailed documents related to the product.
	Turn the automatic saving function on/off.		

See the Operation Manual for detailed information about all the functions.

Functions of parts

■ Top



① Output jacks

Connect a guitar amp or another effect here.

② Input jack

Connect a guitar here.

③ Display

This shows the selected patch memory and its effects, along with their parameter setting values, and other information.

④ Parameter knobs

Use these to adjust effect parameters and make various settings.


⑤ Direction buttons

Use these to select patch memories and effects, for example. They can be operated by foot.

⑥ Footswitch

This turns the effect on/off. Press and hold this to switch to the tuner.


■ Bottom



① Battery cover

Open this when installing or removing AA batteries.

■ Back



① DC 9V AC adapter connector

Connect the dedicated AC adapter (ZOOM AD-16) here.

② USB (Type-C) port

Use this to connect to a computer or an iOS/iPadOS device. This supports operation on USB bus power.

Troubleshooting

The unit will not power on

- Check the connections.
- If using batteries, connect a cable to the INPUT jack.

There is no sound or output is very quiet

- Check the connections.
- Adjust the levels of the effects.
- Adjust the output volume.
- Confirm that the tuner output setting is not "MUTE".

There is a lot of noise

- Confirm that nothing is wrong with the instrument cable.
- Use a genuine AC adapter (ZOOM AD-16).

An effect cannot be selected

- "MAX EFFECTS. DELETE ONE." will appear on the display when trying to add an effect that would exceed the maximum combination limit. Delete one effect before adding another one.

Product names, registered trademarks and company names in this document are the property of their respective companies.

iPadOS is a trademark or registered trademark of Apple Inc.

IOS is a trademark or registered trademark of Cisco Systems, Inc. in the USA and other countries, and it is used under license.

USB Type-C is a trademark of the USB Implementers Forum.

All trademarks and registered trademarks in this document are for identification purposes only and are not intended to infringe on the copyrights of their respective owners.

The illustrations and display screens in this document could differ from the actual product.



ZOOM CORPORATION

4-4-3 Kanda-surugadai, Chiyoda-ku, Tokyo 101-0062 Japan

zoomcorp.com